



REMOS GXiS

Pilot's Operating Handbook for Light Sport Aircraft

Airplane Registration Number _____

Airplane Serial Number _____

REMOS Publication No. 104714, dated December 2017

intentionally left blank

Introduction

Record of Manual Revisions

Please make a notation below if any changes have been made to this manual or to the aircraft. This manual is an important document for the pilot in command to ensure safe operation of the aircraft. Therefore, it is recommended to keep this Operating Handbook updated with the newest information available. You can get the latest updates of this manual from your dealer or directly from the manufacturer’s homepage.

| no. | page | concern | date | sign |
|-----|------|---------|------|------|
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Introduction

List of Content and Revisions

This POH consists of the following listed pages and sections. You will find a marking indicating the revision and date of issue at the top border of each page. Insert the latest changed pages.

| Pilot Operating Handbook – Main Part | | | |
|--------------------------------------|------------------------|-----------------|----------|
| sect. | description | document-no. | revision |
| 0 | Introduction | G3-8 MA FM 9400 | 01 |
| 1 | General Information | G3-8 MA FM 9401 | 01 |
| 2 | Operating Limitations | G3-8 MA FM 9402 | 01 |
| 3 | Emergency Procedures | G3-8 MA FM 9403 | 01 |
| 4 | Normal Procedures | G3-8 MA FM 9404 | 01 |
| 5 | Performance | G3-8 MA FM 9405 | 01 |
| 6 | Weight and Balance | G3-8 MA FM 9406 | 01 |
| 7 | Systems | G3-8 MA FM 9407 | 01 |
| 8 | Handling and Servicing | G3-8 MA FM 9408 | 01 |

| Pilot Operating Handbook – Supplement | | | |
|---------------------------------------|-------------------------|-----------------|----------|
| sect. | description | document-no. | revision |
| 9 | Continued Airworthiness | G3-8 MA FM 9409 | 01 |
| 10 | Continued Airworthiness | G3-8 MA FM 9410 | 01 |

Introduction

Light Sport Aircraft REMOS GXiS

The REMOS **GXiS** was manufactured in accordance with the Light Sport Aircraft airworthiness standards and does not conform to standard category airworthiness requirements.

The standards to be used for certification are given by FAA and can be obtained from the FAA's website. For this airplane the following standards have been used:

| number | revision | purpose |
|------------|----------|---------------------------------|
| ASTM F2245 | 16c | Design and Performance |
| ASTM F2245 | 16c | Required Equipment |
| ASTM F2245 | 16c | Aircraft Operating Instructions |
| ASTM F2972 | 15 | Quality Assurance |
| ASTM F2295 | 06 | Continued Airworthiness |
| ASTM F2483 | 12 | Maintenance Manual |
| ASTM F2746 | 14 | Pilot Operating Handbook |

This table is applicable only for newly delivered aircraft. It is not applicable in case the POH has been updated for existing aircraft.

Manufacturer and Contact Information

REMOS AG Franzfelde 31
 D-17309 Pasewalk
 GERMANY

Phone: +49 3973/225519-0
Fax: +49 3973/225519-99

Internet: www.remos.com

Introduction

Views



wingspan 9,32m (30.6 ft)



height 2.28m (7.3ft)



total length 6,64m (21.8 ft)

1 General Information

Table of Contents

| sect. | description | page |
|-------|--------------------------|------|
| 1.1 | Introduction | 1-2 |
| 1.2 | Certification | 1-2 |
| 1.3 | Continued Airworthiness | 1-2 |
| 1.4 | Quick Reference | 1-3 |
| 1.5 | Technical Specifications | 1-3 |
| 1.6 | Performance | 1-4 |
| 1.7 | Engine | 1-4 |
| 1.8 | Fuel | 1-5 |
| 1.9 | Oil | 1-5 |
| 1.10 | Propeller | 1-6 |
| 1.11 | ICAO Designator | 1-6 |
| 1.12 | Noise Certification | 1-6 |

1 General Information

1.1 Introduction

This Operating Handbook is designed to help enable a safe and successful completion of each flight with the REMOS **GXiS**. It provides you with all necessary information for regular maintenance and operation of the aircraft. Therefore we recommend that the pilot keep this Operating Handbook updated with the newest information available. You can get the latest version of this Handbook from your local dealer or directly from the manufacturer's homepage.

1.2 Certification

The REMOS **GXiS** was manufactured in accordance with the Light Sport Aircraft airworthiness standards and does not conform to standard category airworthiness requirements.

1.3 Continued Airworthiness

Technical publications for continued airworthiness are released on the REMOS website www.remos.com and they may be downloaded free of charge.

Bombardier-Rotax releases technical publications on their website www.flyrotax.com from which they may be downloaded free of charge. Documentation update for avionics may be downloaded on www.dynonavionics.com and www.garmin.com.

It is the responsibility of the owner/operator of the aircraft to keep the aircraft and its documentation up to date and to comply with all technical publications.

1 General Information

1.4 Quick Reference

| | |
|---------|--|
| Type: | Full composite carbon fiber aircraft with two seats. |
| Design: | High wing design with struts, front mounted engine and propeller, traditional stabilizer concept, differential ailerons. Electrically operated flaps (0°, 15° and 35°), electric elevator trim, three-wheel landing gear with steerable nose wheel. Main gear with hydraulic disc brakes. The cabin is equipped with two seats side by side and can be entered and exited by doors on the left and right side of the fuselage. |
| Layout: | Main components are built in half shells from composite fiber material, which are bonded together (carbon fiber, Kevlar and glass fiber). |

1.5 Technical Specifications

| | | |
|--------------|------------------------|------------------|
| wingspan | 9.32 m | (30 ft 7 in) |
| length | 6.64 m | (21 ft 10 in) |
| height | 2.28 m | (7 ft 4 in) |
| wing area | 10.97 m ² | (118 sq ft) |
| MTOW | 600 kg | (1,320lb) |
| wing loading | 54.7 kg/m ² | (11.2 lb/sq ft) |

1 General Information

1.6 Performance

This section shall give a summary of the performance of the REMOS **GXiS**. Detailed performance data is given in section 5 of this Pilot Operating Handbook.

| | | | |
|--------------------------|-------------------|------------|----------------------------|
| top speed at MSL | | 105 KTAS | @° 5,300 rpm |
| cruise speed at 4,000 ft | | 95 KTAS | @° 4,800 rpm (*) |
| range at 4,000 ft | | 451 nm | @° 4,800 rpm (*) |
| endurance at 4,000 ft | | 4.75 h | @° 4,800 rpm (*) |
| rate of climb | at V _X | 680 ft/min | @ V _X = 50 kIAS |
| | at V _Y | 710 ft/min | @ V _Y = 60 kIAS |
| stall speed | flaps clean | 43 kIAS | |
| | flaps 15deg | 40 kIAS | |
| | flaps 35deg | 39 kIAS | |

[*] 30min reserve, 21 USgal usable fuel

1.7 Engine

| | | |
|-------------------|--------------|---------------------------------|
| manufacturer | | Bombardier-Rotax |
| engine type | | 912 iS Sport or 912 iSc Sport |
| max. power | take-off | 73.5 kW / 100 HP |
| | max. cont. | 72.0 kW / 97 HP |
| max. engine speed | take-off | 5,800 rpm |
| | continuous | 5,500 rpm |
| gear ratio | | 2.43 : 1 |
| coolant | type | BASF Glysantin Protect Plus/G48 |
| | mixing ratio | see section 7 |

1 General Information

1.8 Fuel

| | | |
|----------------|--------|--|
| fuel quantity | usable | 21 US gallons |
| | total | 22 US gallons |
| fuel qualities | | Fuel released by actual revision of ROTAX service instruction SI-912i-001, preferably free of ethanol. |

| | |
|------|---|
| NOTE | Please refer to REMOS notification NOT-001 and ROTAX SI-912i-001 latest revision for further information on suitable engine fluids (fuel, oil, cooling liquid, additives, etc). |
| | Have a frequent look on www.flyrotax.com and on www.remos.com for the latest information. |

1.9 Oil

| | | |
|-----------------|------|-----------------------------------|
| engine oil | | oil released by ROTAX SI-912i-001 |
| oil rating | | RON 424 |
| oil quantity | min. | 3.0 ltr (3.2 qts) |
| | max. | 3.5 ltr (3.7 qts) |
| recommended oil | | AeroShell Sport PLUS 4 10W-40 |

| | |
|------|---|
| NOTE | Please refer to REMOS notification NOT-001 and ROTAX SI-912i-001 latest revision for further information on suitable engine fluids (fuel, oil, cooling liquid, additives, etc). |
| | Have a frequent look on www.flyrotax.com and on www.remos.com for the latest information. |

1 General Information

1.10 Propeller

| manufacturer | type | number of blades |
|--------------|-------|------------------|
| DUC Hélices | FLASH | 3 |

1.11 ICAO Designator

ICAO Designator: GX (as per ICAO Doc. 8643)

1.12 Noise Certification

According to noise requirements for Ultralight aircraft (LS-UL) dated August 1996, the REMOS **GXiS** is certified to a noise level of 60 dB (A).

2 Operating Limitations

Table of Contents

| sect. | description | page |
|-------|---|------|
| 2.1 | Reference Airspeeds | 2-2 |
| 2.2 | Airspeed Indicator Range and Markings | 2-3 |
| 2.3 | Stalling Speeds at Maximum Takeoff Weight | 2-3 |
| 2.4 | Flap Extended Speed Range | 2-4 |
| 2.5 | Operating Maneuvering Speed | 2-4 |
| 2.6 | Never Exceed Speed | 2-5 |
| 2.7 | Service Ceiling | 2-5 |
| 2.8 | Load Factors | 2-5 |
| 2.9 | Approved Flight Maneuvers | 2-6 |
| 2.10 | Prohibited Maneuvers | 2-6 |
| 2.11 | Crosswind and Wind Limitations | 2-6 |
| 2.12 | Engine | 2-7 |
| 2.13 | Fuel | 2-8 |
| 2.14 | Oil | 2-8 |
| 2.15 | Maximum Wind Velocity for Tie-Down | 2-9 |
| 2.16 | Maximum Structure Temperature | 2-9 |
| 2.17 | Weight and Balance | 2-9 |
| 2.18 | Crew | 2-9 |
| 2.19 | Flight Conditions | 2-10 |
| 2.20 | Placards and Markings – Inside cabin | 2-12 |
| 2.21 | Placards and Markings – Outside Cabin | 2-18 |

2 Operating Limitations

2.1 Reference Airspeeds

| speed | | IAS | description |
|-----------------|---------------------------------------|------------------|---|
| V _{NE} | never exceed speed | 135 kts | airspeed which shall never be exceeded |
| V _{NO} | maximum speed in turbulence | 107 kts | airspeed which shall not be exceeded in gusty weather |
| V _O | operating maneuvering speed | 59 kts 88 kts | maximum airspeed for all permissible maneuvers with 880 lb (400kg) all up weight with 1,320lb (600kg) all up weight |
| V _{FE} | max. speed with flaps fully extended | 78 kts | airspeed which may never be exceeded with flaps down |
| V _T | target airspeed | 60 kts | recommended airspeed for approach at gross weight |
| V _Y | airspeed for best rate of climb | 60 kts | airspeed for the greatest altitude gain in the shortest time, flaps up |
| V _X | airspeed for best angle of climb | 50 kts | airspeed for the steepest climb any flap setting |
| V _S | stall speed with flaps retracted (0°) | 43 kts | stall speed at gross weight with flaps up |
| V _{S0} | stall speed with flaps extended (35°) | 39 kts | stall speed at gross weight with flaps down |

2 Operating Limitations

2.2 Airspeed Indicator Range and Markings

| marking | IAS | range | description |
|------------|---------------|-------------------|-----------------------------------|
| white arc | 39...78 kts | $V_{S0} - V_{FE}$ | airspeed range for flaps extended |
| green arc | 43...107 kts | $V_{S1} - V_{NO}$ | normal use |
| yellow arc | 107...135 kts | $V_{NO} - V_{NE}$ | caution in gusty conditions |
| red line | 135 kts | V_{NE} | maximum permissible airspeed |

The yellow arc defines the “caution” range in which the aircraft should be flown with care as vertical gusts can damage the airframe structure. At V_{NO} the airframe is able to support a gust with 3.000 ft/min, at V_{NE} the vertical gust velocity is limited to 1.500 ft/min.

2.3 Stalling Speeds at Maximum Takeoff Weight

stall speed with flaps extended
 stall speed with flaps retracted

$V_{S0} = 39$ kIAS
 $V_S = 43$ kIAS

2 Operating Limitations

2.4 Flap Extended Speed Range

Flaps may be operated and the aircraft may be flown at airspeeds higher than V_{FE} as long as flap deflection is limited. Following restrictions apply as a function of airspeed:

| δ [deg] | V_{FE} [kIAS] |
|---------------------|----------------------|
| 0 | 135 |
| 15 | 113 |
| 35 | 78 |

With flaps set to any deflection the safe load factor is limited to 2.

2.5 Operating Maneuvering Speed

operating maneuvering speed $V_O = 88$ kIAS
with 600kg all up weight

operating maneuvering speed $V_O = 59$ kIAS
with 400kg all up weight

For any weight between 400kg and 600kg, the operating maneuvering airspeed may be interpolated linearly.

At operating maneuvering speed one control, i.e. **either** aileron, **or** elevator **or** rudder control, may deflected until its stop **once**. Above V_A permissible deflection is reduced, until at never exceed speed V_{NE} only one third of the deflection is permitted.

2 **Operating Limitations**

2.6 Never Exceed Speed

never exceed speed V_{NE} = 135 kTAS

Due do the reduced density of air at altitude, true airspeed is higher than calibrated or indicated airspeed. Therefore, V_{NE} is limited to 135 kts true airspeed in order to prevent flutter. With increasing altitude V_{NE} is limited to lower values than indicated by redline according to the following table.

| altitude [ft] | V _{NE} [kTAS] | V _{NE} [kIAS] |
|--------------------|-----------------------------|-----------------------------|
| 0 | 135 | 135 |
| 5,000 | | 125 |
| 10,000 | | 116 |
| 15,000 | | 107 |

At never exceed speed V_{NE} only one third of the maximum control deflection (aileron, elevator, rudder) is permitted.

2.7 Service Ceiling

service ceiling 15,400 ft

2.8 Load Factors

safe load factors +4.0 g / -2.0 g

With flaps set to any deflection the safe load factor is limited to 2.

2 Operating Limitations

2.9 Approved Flight Maneuvers

The following maneuvers are permitted

- all non-aerobatic maneuvers, including stalls and departure stalls

2.10 Prohibited Maneuvers

Flight maneuvers not permitted

- whip stalls
- aerobatics
- spins
- flight in icing conditions

2.11 Crosswind and Wind Limitations

maximum demonstrated cross wind
component for take-off and landing 15 knots

The maximum demonstrated crosswind component is not a limitation. The pilot may exceed this demonstrated crosswind component on his or her own discretion. In case the pilot operates the aircraft in crosswind components higher than demonstrated he or she shall be aware of the fact that this flight regime has not been tested. A general wind limitation is not defined for the REMOS **GXiS**.

2 Operating Limitations

2.12 Engine

| | | |
|-------------------|--------------|--|
| manufacturer | | Bombardier Recreational Products Rotax |
| engine type | | 912 iS Sport |
| max. power | take-off | 73.5 kW / 100 HP |
| | max. cont. | 69.0 kW / 95 HP |
| max. engine speed | take-off | 5,800 rpm |
| | continuous | 5,500 rpm |
| gear ratio | | 2.43 : 1 |
| exhaust gas temp | max | 950°C |
| coolant | type | BASF Glysantin Protect Plus G48 |
| | mixing ratio | see section 7 |
| coolant temp | min | not defined |
| | max | 120°C = 248°F |

| | |
|-------------|--|
| NOTE | Please refer to REMOS notification NOT-001 and ROTAX SI-912i-001 for further information on suitable engine fluids (fuel, oil, cooling liquid, additives, etc). |
| | Have a frequent look on www.flyrotax.com and on www.remos.com for the latest information. |

2 Operating Limitations

2.13 Fuel

| | | |
|----------------|--------|--|
| fuel quantity | usable | 80 ltr (21 US gallons) |
| | total | 84 ltr (22 US gallons) |
| fuel pressure | min. | 2.8 bar = 40.5 psi |
| | max. | 3.2 bar = 46.5 psi |
| fuel qualities | | Fuel released by actual revision of ROTAX service instruction SI-912i-001, preferably free of ethanol. |

| | |
|-------------|--|
| NOTE | Fuel pressure varies with engine speed. Limits given above apply for normal operation in flight (4,200 – 5,800 rpm). Fuel pressure with engine idling may be less. |
|-------------|--|

2.14 Oil

| | | | |
|-----------------|------|--|-----------------|
| engine oil | | oil released by actual revision of ROTAX service instruction SI-912i-001 | |
| oil rating | | RON 424 | |
| oil quantity | min. | 3.0 ltr | (3.2 qts) |
| | max. | 3.5 ltr | (3.7 qts) |
| recommended oil | | AeroShell Sport PLUS 4 10W-40 | |
| oil pressure | min. | 0.8 bar = 12 psi | (below 3500rpm) |
| | | 2.0 bar = 29 psi | (above 3500rpm) |
| | max. | 7.0 bar = 102 psi | |
| oil temperature | min. | 50°C | (120°F) |
| | max. | 130°C | (266°F) |

| | |
|-------------|--|
| NOTE | <p>Please refer to REMOS notification NOT-001 and ROTAX SI-912-016/SI-914-019 for further information on suitable engine fluids (fuel, oil, cooling liquid, additives, etc).</p> <p>Have a frequent look on www.flyrotax.com and on www.remos.com for the latest information.</p> |
|-------------|--|

2 Operating Limitations

2.15 Maximum Wind Velocity for Tie-Down

max. wind velocity for tie-down in the open $V_R = 38 \text{ kts}$

2.16 Maximum Structure Temperature

max. certified structure temperature 54°C

2.17 Weight and Balance

| | | |
|-------------------------------------|----------|---------|
| front limit of C.G. | 9.6 in | 245 mm |
| rear limit of C.G. | 16.3 in | 415 mm |
| maximum take-off weight (MTOW) | 1,320 lb | 600 kg |
| max. baggage in baggage compartment | 66 lb | 30 kg |
| max. baggage in each bin | 4.4 lb | 2 kg |
| max. fuel | 133 lb | 60.5 kg |

2.18 Crew

The REMOS **GXis** is certified to be operated with a minimum of 1 occupant (the pilot in command) and a maximum of 2 occupants.

REMOS does not define a seat for the pilot in command. The seat of the pilot in command may be otherwise defined by regulations or by the owner/operator.

2 Operating Limitations

2.19 Flight Conditions and Minimum Equipment List

| operation | minimum equipment |
|------------|---------------------------------------|
| Day-VFR | as per D-VFR Minimum Equipment List |
| Night-VFR | as per N-VFR Minimum Equipment List |
| IFR in IMC | not approved |
| IFR in VMC | as per IFR/VMC Minimum Equipment List |
| Aerobatics | not approved |

D-VFR minimum equipment list

- ROTAX 912 iS Sport
- silencer
- propeller as defined in chapter 2
- compass (*)
- altimeter (*)
- airspeed indicator (*)
- safety belts and seat for each occupant
- ELT
- electrical system including SMARTstart System, ignition key and circuit breakers
- engine instruments (*)

(*) information displayed in glass cockpit only is acceptable

2 Operating Limitations

N-VFR Minimum equipment list

- as per D-VFR minimum equipment list, plus
- electrical artificial horizon (*)
- instrument panel lighting
- position lights
- taillight
- anti collision lights
- landing light
- communication radio
- transponder

IFR/VMC Minimum equipment list




- as per N-VFR minimum equipment list, plus
- navigation radio
- audio panel

(*) information displayed in glass cockpit only is acceptable

2 Operating Limitations

2.20 Placards and Markings Inside Cabin





The placards and markings feature the following color codes.

| Type | Inside |
|-------------|---|
| Information | white lettering on a black background - white framed  |
| Safety | white lettering on a black background - red framed  |
| Warning | white lettering on a red background - white framed  |




The following list does not define the layout but the content and intent of the placards.

2 Operating Limitations

The following information placards are installed inside the cabin. Installation of these placards is **mandatory**.










| placard | location |
|---|---|
|  | center stack actual callsign of aircraft |
|  | center stack between lane reset switches |
|  | center stack at engine test button |
|  | center stack around ignition key |

2 Operating Limitations



| placard | location |
|--|--|
|  | center console at power lever |
|  | left panel labeled with CB's installed |
|  | right panel labeled with CB's installed |

2 Operating Limitations

The following safety placards are installed inside the cabin. Installation of these placards is **mandatory**.

| placard | location |
|--|---|
|   | left cockpit above left cockpit screen |
|  | left cockpit above left cockpit screen installed in combination with towing clutch only |
|  | center stack on top of center stack |
|  This Aircraft was manufactured in accordance with Light Sport Aircraft airworthiness standards and does not conform to standard category airworthiness requirements. | right cockpit above right cockpit screen |
|  | hatrack between baggage nets |
|  | fuel tank sight hose indicating minimum fuel level |
|   | cabin ceiling at recovery system release handle when recovery system is installed |
|  | aileron pushrod |

2 Operating Limitations








| placard | location |
|---|--|
|  | aileron pushrod cut out |
|  | baggage compartment when recovery system is installed |

The following warning placards are installed inside the cabin. Installation of these placards is **mandatory**.


| placards | location |
|---|----------|
|  | door |
|  | door |

2 Operating Limitations

The following information placards and markings are found inside the cabin. Attaching these placards is not mandatory; these placards provide additional information to the pilot.

| placards | location |
|---|--|
|  | <p>center stack</p> <p>at flap switch</p> |
|  | <p>center stack</p> <p>at landing light switch</p> |
|  | <p>center stack</p> <p>at panel light dimmer</p> |
|  | <p>inside armrest</p> <p>on brake fluid reservoir</p> |
|  | <p>baggage compartment</p> <p>on compartment cover imperial units acceptable</p> |
|  | <p>hatrack</p> <p>close to baggage nets imperial units acceptable</p> |
|  | <p>center stack</p> <p>around air/heat control knobs</p> |

2 Operating Limitations

| placards | location |
|---|--|
|  | armrest at parking brake valve |

2 Operating Limitations

2.21 Placards and Markings Outside Cabin


The placards and markings feature the following color codes.

| Type | Outside |
|-------------|--|
| Information | black lettering on a white background - black framed |
| | <div>Information</div> |
| Safety | red lettering on a white background - red framed |
| | <div>Safety</div> |
| Warning | red lettering on a white background - red framed |
| | <div>! Warning !</div> |

The following list does not define the layout but the content and intent of the placards.




2 Operating Limitations

The following information placards are installed outside the cabin.
Installation of these placards is ***mandatory***.

| placards | location |
|---|--|
|  | <p>fuel tank filler cap</p> <p>metric units acceptable</p> |

2 Operating Limitations

The following safety placards are installed outside the cabin. Installation of these placards is **mandatory**.


| placards | location |
|---|--|
|  | center of elevator |
|  | next to the opening for aileron pushrod, covered by wing if not folded |
|  | center of fixed surface of elevator, covered if elevator is installed |

The following warning placards are installed outside the cabin. Installation of these placards is **mandatory**.

| placards | location |
|---|---|
|  | recovery system egress area when recovery system installed |

2 Operating Limitations

The following information placards and markings are found outside the cabin. Attaching these placards is not mandatory; these placards provide additional information to the pilot.

| placards | location |
|---|---|
| <div>2,0 BAR MAX</div> <div>29 PSI MAX</div> <div>2,4 BAR MAX</div> <div>34 PSI MAX</div> | wheel fairings placard set with one unit only acceptable |
|  | static ports |

The following safety placards and markings are found outside the cabin. Attaching these placards is not mandatory; these placards provide additional information to the pilot.

| placards | location |
|---|--|
| <div> ! WARNING ! Before removing wing bolt disconnect aileron rod-connection! </div> | wing main bolt |
| <div> ! WARNING ! Wing not foldable ! </div> | wing when wing folding mechanism not installed |
| <div> Do not lift </div> | strut |

3 Emergency Procedures

Table of Content

| sect. | description | page |
|-------|----------------------------------|------|
| 3.1 | Definitions | 3-3 |
| 3.2 | Jettison of Doors | 3-4 |
| 3.3 | Spin Recovery | 3-4 |
| 3.4 | Recovery System | 3-4 |
| 3.5 | Emergency Descent | 3-4 |
| 3.6 | Inadvertent Icing Encounter | 3-5 |
| 3.7 | Loss of Altimeter | 3-5 |
| 3.8 | Loss of Airspeed Indicator | 3-6 |
| 3.9 | Total Loss of Glass Cockpit | 3-7 |
| 3.10 | Loss of Elevator Control | 3-8 |
| 3.11 | Loss of Aileron Control | 3-9 |
| 3.12 | Loss of Rudder Control | 3-10 |
| 3.13 | Loss of Trim System | 3-11 |
| 3.14 | Loss of Flap Control System | 3-12 |
| 3.15 | Loss of Oil Pressure | 3-13 |
| 3.16 | High Oil Pressure | 3-14 |
| 3.17 | High Cylinder Head Temperature | 3-15 |
| 3.18 | Engine Stoppage during Take-Off | 3-16 |
| 3.19 | Engine Stoppage in Flight | 3-17 |
| 3.20 | Engine on Fire During Start-Up | 3-18 |
| 3.21 | Engine on Fire During Take-Off | 3-18 |
| 3.22 | Engine on Fire in Flight | 3-19 |
| 3.23 | Rough Engine | 3-19 |
| 3.24 | Loss of Power | 3-20 |
| 3.25 | Generator Failure / Voltage Drop | 3-21 |
| 3.26 | Battery Warning | 3-22 |
| 3.27 | Over-Voltage | 3-23 |

3 Emergency Procedures

| sect. | description | page |
|-------|----------------------------------|------|
| 3.28 | Flight with INOP Generator(s) | 3-24 |
| 3.29 | Miscellaneous Engine Trouble | 3-25 |
| 3.30 | Flight with ONE deactivated LANE | 3-28 |
| 3.31 | Flight with ONE INOP Fuel Pump | 3-28 |
| 3.32 | Precautionary Landing | 3-29 |
| 3.33 | Emergency Landing on Land | 3-30 |
| 3.34 | Emergency Landing on Water | 3-30 |

3 Emergency Procedures

3.1 Definitions

Procedures

are instructions that must be performed in the given sequence, as far as possible without interruption.

Checklists

are lists for items to be checked in the applicable phase of flight (taxi, take-off, climb, etc.). Timing and sequence of the steps to be executed may vary according to the individual flight.

Briefings

are guidelines for upcoming procedures. With the help of briefings, the pilot and passenger should recapitulate those procedures.

3 Emergency Procedures

3.2 Jettison of Doors Procedure

- | | |
|--------------|----------|
| 1. door lock | OPEN |
| 2. hinge pin | PULL |
| 3. door | JETTISON |

3.3 Spin Recovery Procedure

- | | |
|-------------------------------|-------------------------|
| 1. engine | IDLE |
| 2. control stick | NEUTRAL |
| 3. rudder | OPPOSITE SPIN DIRECTION |
| 4. after stopping of rotation | RECOVER |

3.4 Recovery System Procedure

- | | |
|----------------------|----------------------|
| 1. engine | STOP |
| 2. recovery system | RELEASE |
| 3. declare emergency | MAYDAY MAYDAY MAYDAY |
| 4. master switch | OFF |
| 5. safety belts | TIGHTEN |

3.5 Emergency Descent Procedure

- | | |
|--------------------------|----------|
| 1. engine | IDLE |
| 2. flaps | UP |
| 3. airspeed in rough air | 107 KIAS |
| airspeed in calm air | 135 KTAS |

3 Emergency Procedures

3.6 Inadvertent Icing Encounter Procedure

- | | |
|-----------------------|--------------------------|
| 1. engine | FULL POWER |
| 2. flaps | UP |
| 3. carburetor heat | PULL |
| 4. electric fuel pump | ON |
| 5. heading change | BACKTRACK |
| 6. descent | LEAVING ICING CONDITIONS |
| 7. altitude | KEEP SAFE ALTITUDE |

3.7 Loss of Altimeter Procedure

for aircraft with more than one altimeter installed

1. AVIATE – NAVIGATE – COMMUNICATE
2. altimeter USE ALTERNATE ALTIMETER
3. in case of failure of all altimeters installed continue with procedure below

aircraft with just one altimeter and within airspace requiring clearance

1. radio communication INFORM ATC
2. instructions by ATC ACT ACCORDINGLY
3. continue flight and land on appropriate airfield to determine the reason for the altimeter failure

aircraft with just one altimeter but outside airspace requiring clearance

1. altitude KEEP SAFE ALTITUDE
2. instructions by ATC ACT ACCORDINGLY
3. continue flight and land on appropriate airfield to determine the reason for the altimeter failure

3 Emergency Procedures

3.8 Loss of Airspeed Indicator Procedure

for aircraft with more than one airspeed indicator installed

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. airspeed indicator USE ALTERNATE ASI
- 3. in case of failure of all airspeed indicators installed continue with procedure below

for aircraft with one airspeed indicator installed or total failure of ASI

- 1. engine speed in cruise 4.200...4.600 rpm

landing without airspeed indicator

- 1. airfield APPROPRIATE RWY LENGTH
- 2. flaps UP
- 3. carburetor heat PULL
- 4. electric fuel pump ON
- 5. engine speed in decent 2.500...3.000 rpm
- 6. pitch KEEP WITHIN estd. +/-10 deg
- 7. short final approach POWER IDLE
- 8. flare AS APPROPRIATE
- 9. touch down on main wheels first with very little flare.
- 10. brakes IMMEDIATELY

| | |
|------|---|
| NOTE | Landing distance with this procedure is significantly longer than a standard landing. Expect distances far in excess of 2.000 ft / 600m or even more. Select an airfield with sufficient runway length available. |
|------|---|

3 Emergency Procedures

3.9 Total Loss of Glass Cockpit Procedure

failure of one glass screen (frozen or black)

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. glass screen USE ALTERNATE SCREEN
- 3. continue flight and land on appropriate airfield to determine the reason for the failure

failure of both glass screens (frozen or black)

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. glass screen IGNORE
- 3. flight instruments USE STAND-BY INSTRUMENTS
- 4. continue flight and land on appropriate airfield to determine the reason for the failure

| | |
|------|---|
| NOTE | Even the total loss of the glass cockpit system does not lead to an immediate emergency. Losing both screens leads to loss of engine indication. This will not lead to engine problems or engine failure. Continue flight to appropriate destination. |
|------|---|

| | |
|------|--|
| NOTE | Failure of the glass screens might lead to failure, misleading or missing warning of the stall warning. Check accuracy of ASI and altimeter (compare with GPS). Assume the stall warning has failed. |
|------|--|

3 Emergency Procedures

3.10 Loss of Elevator Control Procedure

aircraft equipped with recovery system

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. declare emergency MAYDAY MAYDAY MAYDAY
- 3. recovery system DEPLOY

aircraft without recovery system

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. declare emergency MAYDAY MAYDAY MAYDAY
- 3. power setting FOR LEVEL FLIGHT
- 4. elevator control USE TRIM SYSTEM
- 5. landing EMERGENCY LANDING

| | |
|------|---|
| NOTE | With a failed elevator control the aircraft might be controlled with the trim system. Pitch control is extremely limited. Engine power control might support pitch control. |
|------|---|

| | |
|------|---|
| NOTE | <p>stuck/blocked elevator control UP trim will result in a nose down response DOWN trim will result in a nose up response</p> <p>disconnected/floating elevator control UP trim will result in a nose up response DOWN trim will result in a nose down response</p> |
|------|---|

| | |
|---------|---|
| WARNING | Loss of elevator control is an extremely severe situation that might result in loss of control of the aircraft, serious injuries or even death. |
|---------|---|

3 Emergency Procedures

3.11 Loss of Aileron Control Procedure

aircraft equipped with recovery system

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. declare emergency MAYDAY MAYDAY MAYDAY
- 3. recovery system DEPLOY

aircraft without recovery system

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. declare emergency MAYDAY MAYDAY MAYDAY
- 3. power setting FOR LEVEL FLIGHT
- 4. control USE RUDDER CONTROL
- 5. landing EMERGENCY LANDING

| | |
|------|--|
| NOTE | With a failed aileron control the aircraft might be controlled with the rudder control resulting in excessive sideslip conditions. |
|------|--|

| | |
|---------|--|
| WARNING | Loss of aileron control is an extremely severe situation that might result in loss of control of the aircraft, serious injuries or even death. |
|---------|--|

3 Emergency Procedures

3.12 Loss of Rudder Control Procedure

aircraft equipped with recovery system

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. declare emergency MAYDAY MAYDAY MAYDAY
- 3. recovery system DEPLOY

aircraft without recovery system

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. declare emergency MAYDAY MAYDAY MAYDAY
- 3. power setting FOR LEVEL FLIGHT
- 4. control USE AILERON CONTROL
- 5. landing EMERGENCY LANDING

| | |
|------|--|
| NOTE | With a failed rudder control the aircraft might be controlled with the aileron control resulting in excessive sideslip conditions. |
|------|--|

| | |
|---------|---|
| WARNING | Loss of rudder control is an extremely severe situation that might result in loss of control of the aircraft, serious injuries or even death. |
|---------|---|

3 Emergency Procedures

3.13 Loss of Trim System

Procedure

pitch down trim runaway or stuck trim with lot of trim down

1. AVIATE – NAVIGATE – COMMUNICATE
2. expect nose down attitude
3. keep nose up with manual stick input
4. release trim circuit breaker
5. expect higher stick forces than usual
6. continue flight and land on appropriate airfield to determine the reason for the trim system failure

pitch up trim runaway or stuck trim with lot of trim up

1. AVIATE – NAVIGATE – COMMUNICATE
2. expect nose up attitude
3. keep nose level with manual stick input
4. release trim circuit breaker
5. expect higher stick forces than usual
6. continue flight and land on appropriate airfield to determine the reason for the trim system failure

| | |
|------|---|
| NOTE | The aircraft is controllable even with a complete trim runaway. Keep your airspeed below V _{NO} to keep stick forces within reasonable limits. |
|------|---|

3 Emergency Procedures

3.14 Loss of Flaps Control System Procedure

flaps stuck in deflected position or flaps down runaway

1. AVIATE – NAVIGATE – COMMUNICATE
2. max. flap speed $V_{FE} = 78 \text{ kIAS}$
3. approach airspeed $V_{APP} = 60 \text{ kIAS}$
4. return to airfield or continue flight and land on appropriate airfield to determine the reason of the failure

flaps stuck in retracted position or flaps up runaway

1. AVIATE – NAVIGATE – COMMUNICATE
2. stall speed $V_S = 43 \text{ kIAS}$
3. approach airspeed $V_{APP} = 60 \text{ kIAS}$
4. return to airfield or continue flight and land on appropriate airfield to determine the reason of the failure

NOTE

Keep in mind that landing distances presented in section 5 of this POH are applicable to the normal landing procedure. Landing with flaps up will result in longer landing distances.

3 Emergency Procedures

3.15 Loss of Oil Pressure Procedure

oil temperature not stable (constantly and rapidly rising)

smell of oil, oil fumes, oil on windscreen

5. AVIATE – NAVIGATE – COMMUNICATE
6. PERFORM PRECAUTIONARY LANDING

oil temperature stable (constant oil temperature)

no obvious oil leakage, engine running smooth

1. monitor oil temperature STABLE
2. CHT max. 248°F = 120°C
3. oil temperature 120...266°F = 50...130°C
4. continue flight and land on appropriate airfield to determine the reason for the indicated oil pressure loss

WARNING

Loss of oil pressure may be a result of an oil leakage. This is an extremely dangerous situation as it implies the immediate danger of an in-flight fire. Be sensitive to any kind of abnormal smell or fire. Be prepared for an immediate precautionary landing, maybe emergency landing!

3 Emergency Procedures

3.16 High Oil Pressure Procedure

oil temperature not stable (constantly and rapidly rising)

smell of oil, oil fumes, oil on windscreen

1. AVIATE – NAVIGATE – COMMUNICATE
2. PERFORM PRECAUTIONARY LANDING

oil temperature stable (constant oil temperature)

no obvious oil leakage, engine running smooth

1. monitor oil temperature STABLE
2. CHT max. 248°F = 120°C
3. oil temperature 120...266°F = 50...130°C
4. continue flight and land on appropriate airfield to determine the reason for the indicated high oil pressure

WARNING

High oil pressure may result in an oil leakage. This is an extremely dangerous situation as it implies the immediate danger of an in-flight fire. Be sensitive to any kind of abnormal smell or fire. Be prepared for an immediate precautionary landing, maybe emergency landing!

3 Emergency Procedures

3.17 High Cylinder Head Temperature Procedure

1. AVIATE – NAVIGATE – COMMUNICATE
2. power setting REDUCE TO MIN. POSSIBLE
3. continue flight and land on appropriate airfield to determine the reason of the high cylinder head temperature
4. record max. observed temperature and duration

NOTE

The engine has water cooled cylinder heads. Therefore, a failure of the cooling system does not imply immediate danger of engine failure.

NOTE

In case cylinder head temperature can be kept within limits (max. 248°F = 120°C) flight can be continued to planned destination.

NOTE

In case cylinder head temperature rises uncontrollable be prepared for precautionary landing, although the engine is not expected to stop suddenly.

NOTE

The ROTAX manual gives advice for inspection and release to service after such an occurrence.

3 Emergency Procedures

3.18 Engine Stoppage during Take-Off Procedure

during take-off run (aborted take-off)

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. brakes AS REQUIRED
- 3. ignition key OFF

during climb out (altitude below 500ft)

- 1. AVIATE – NAVIGATE – COMMUNICATE
- 2. declare emergency MAYDAY MAYDAY MAYDAY
- 3. ignition key OFF
- 4. safety belts TIGHTEN
- 5. emergency landing APPROPRIATE TERRAIN

| | |
|------|---|
| NOTE | No course deviations should be made in excess of 30° to the left or right. Do not return to the airfield. |
|------|---|

3 Emergency Procedures

3.19 Engine Stoppage in Flight Procedure

case 1: altitude not enough for engine re-start

- | | | |
|----|---------------------------------|----------------------|
| 1. | AVIATE – NAVIGATE – COMMUNICATE | |
| 2. | landing site | IDENTIFY |
| 3. | declare emergency | MAYDAY MAYDAY MAYDAY |
| 4. | safety belts | TIGHTEN |
| 5. | emergency landing | APPROPRIATE TERRAIN |

case 2: altitude sufficient for engine re-start

- | | | |
|----|---------------------------------|----------------------|
| 1. | AVIATE – NAVIGATE – COMMUNICATE | |
| 2. | landing site | IDENTIFY |
| 3. | emergency switch | PULL to ON and START |
| 4. | SkyView LH | STAY ON |
| 5. | landing light | OFF |
| 6. | landing | SUITABLE AIRFIELD |

| | |
|------|---|
| NOTE | <p>By engaging the emergency mode non-essential systems are switched off, i.e.:</p> <ul style="list-style-type: none">• SkyView (has internal backup battery)• NAV lights and strobes• Autopilot• Second COM• 12 V receptacle <p>Selecting STAY ON on the SkyView keeps the system powered on internal backup batteries. Switching on or off the SkyView system is done by pressing the left softkey. It is recommended to have only one SkyView switched on at a time.</p> |
|------|---|

| | |
|---------|---|
| WARNING | <p>When engine failure is caused by double generator failure, remaining flight time is not more than 30min. Thereafter the engine will definitely and finally quit.</p> |
|---------|---|

3 Emergency Procedures

3.20 Engine on Fire During Start-Up Procedure

- | | |
|--------------------|-------------|
| 1. ignition key | OFF |
| 2. vacate aircraft | IMMEDIATELY |

3.21 Engine on Fire During Take-Off Procedure

during take-off run (aborted take-off)

- | | |
|------------------------------------|------------------------|
| 1. AVIATE – NAVIGATE – COMMUNICATE | |
| 2. ignition key | OFF |
| 3. brakes | AS REQUIRED UNTIL STOP |
| 4. vacate aircraft | IMMEDIATELY |

during climb out (altitude below 500ft)

- | | |
|------------------------------------|------------------------|
| 1. AVIATE – NAVIGATE – COMMUNICATE | |
| 2. declare emergency | MAYDAY MAYDAY MAYDAY |
| 3. ignition key | OFF |
| 4. safety belts | TIGHTEN |
| 5. emergency landing | APPROPRIATE TERRAIN |
| 6. vacate aircraft | IMMEDIATELY AFTER STOP |

| | |
|------|---|
| NOTE | No course deviations should be made in excess of 30° to the left or right. Do not return to the airfield. |
|------|---|

| | |
|---------|--|
| WARNING | Never release the recovery system in case of fire. |
|---------|--|

3 Emergency Procedures

3.22 Engine on Fire in Flight Procedure

- | | | |
|----|---------------------------------|----------------------|
| 1. | AVIATE – NAVIGATE – COMMUNICATE | |
| 2. | declare emergency | MAYDAY MAYDAY MAYDAY |
| 3. | ignition key | AVIONIC (engine off) |
| 4. | sideslip | AS REQUIRED |
| 5. | safety belts | TIGHTEN |
| 6. | emergency landing | APPROPRIATE TERRAIN |

| | |
|---------|--|
| WARNING | Never release the recovery system in case of fire. |
|---------|--|

3.23 Rough Engine Procedure

- | | | |
|----|--------------|-------------------|
| 1. | Lane A | RESET |
| 2. | Lane B | RESET |
| 3. | corrupt lane | DEAKTIVATE |
| 4. | landing | SUITABLE AIRFIELD |

| | |
|------|--|
| NOTE | LANE RESET means to switch off the affected LANE (flashing or permanent warning light) and after a couple of seconds to switching it on again. |
|------|--|

3 Emergency Procedures

3.24 Loss of Power Procedure

1. AVIATE – NAVIGATE – COMMUNICATE
2. landing site IDENTIFY
3. power and setting CHECK

power not sufficient for safe flight

4. declare emergency MAYDAY MAYDAY MAYDAY
5. safety belts TIGHTEN
6. ignition key AVIONIK
7. emergency landing SUITABLE TERRAIN

power sufficient

4. landung SUITABLE AIRFIELD

3 Emergency Procedures

3.25 Generator Failure / Voltage Drop Procedure

- | | |
|------------------------------------|---|
| 1. AVIATE – NAVIGATE – COMMUNICATE | |
| 2. Identification | LANE A and B FLASHING and or LOW VOLTAGE WARNING |
| 3. emergency switch | LIFT and ENGAGE |
| 4. SkyView LH | press STAY ON |
| 5. landing light | OFF |

| | |
|------|---|
| NOTE | <p>By engaging the emergency mode non-essential systems are switched off, i.e.:</p> <ul style="list-style-type: none">• SkyView (has internal backup battery)• NAV lights and strobes• Autopilot• Second COM• 12 V receptacle <p>Selecting STAY ON on the SkyView keeps the system powered on internal backup batteries. Switching on or off the SkyView system is done by pressing the left softkey. It is recommended to have only one SkyView switched on at a time.</p> |
|------|---|

| | |
|---------|---|
| WARNING | <p>Sudden double generator failure leads to engine failure. Engine restart is possible. Remaining flight time is not more than 30min. Thereafter the engine will definitely and finally quit.</p> |
|---------|---|

| | |
|---------|---|
| WARNING | <p>Usually a single generator failure is observed prior to a double generator failure. Sudden double generator failure leads to engine failure.</p> |
|---------|---|

3 Emergency Procedures

3.26 Battery Warning

Checklist

If installed, battery warning is coming up as lighting or flashing battery status light in the DYNON SkyView system. Proceed as follows:

warning light flashing

| voltage | possible cause | action |
|-------------------|---|--|
| < 13.2 V | battery over-discharged | Charge battery on ground. Once charged, the light will stop flashing. |
| < 13.2 V | weak or failing cell | Charge battery on ground. If voltage drops below 13.2V within a few days, discontinue use. |
| 13.2 V ... 14.6 V | weak or failing cell | Discontinue use. If in flight, this is not an immediate issue unless it is in conjunction with a charging system failure. |
| 13.2 V ... 14.6 V | cell to cell charge levels are not balanced | May come on briefly during periods of high current charging until the cells are automatically balanced. Try charging with a plugin charger. |
| > 15.2 V | over-charging | Both the aircraft voltage regulator and aircraft overvoltage protection have failed. Land on appropriate airfield, soon. Consider precautionary landing. |

warning light permanently on

| voltage | possible cause | Recommended action |
|----------------|--|---|
| any | battery management system electronic issue | Not an immediate issue unless it is in conjunction with a charging system failure. In this case: Both the aircraft voltage regulator and aircraft overvoltage protection have failed. Land on appropriate airfield, soon. Consider precautionary landing. |
| any | short circuit protection was activated | Solid light will turn off without further action, noting needs to be done. |

3 Emergency Procedures

3.27 Over-Voltage

Procedure

The aircraft is equipped with an overvoltage protection. This subsystem protects the aircraft systems and the avionics in case of an overvoltage event.

The overvoltage protection is integrated into the PSU (power supply unit) and needs neither maintenance not operation. In case the overvoltage protection releases due to a voltage regulator failure, it isolates the electric system from the engine charging system

In such an event, the overvoltage warning light in the DYNON system lights up, followed by a low voltage warning. For the pilot, this has the identical effect as a generator failure: charging power of the generators is not available anymore and the aircraft batteries will discharge.

1. AVIATE – NAVIGATE – COMMUNICATE

2. Identification

3. emergency switch

4. SkyView LH

5. landing light

LANE A and B FLASHING and
or LOW VOLTAGE WARNING

LIFT and ENGAGE

press STAY ON

OFF

| | |
|------|---|
| NOTE | The procedure is identical as defined in section 3.24 - <i>generator failure</i> . Once the emergency mode is activated, section 3.27 - <i>flight with INOP generator(s)</i> applies. |
|------|---|

3 Emergency Procedures

3.28 Flight with INOP Generator(s) Briefing

The engine is equipped with two generators – one for the engine systems (ignition, fuel pumps, ECU, fuse box) and a second one for the aircraft systems.

After a single generator failure, the ECU switches to the remaining generator to ensure safe operation of the engine. Therefore, a single generator failure does not cause a dangerous situation.

After a single generator failure, the aircraft systems are powered by the aircraft batteries only. Engaging the emergency mode by switching the emergency switch on will provide excess power of the remaining generator to the electric system, which is also still supported by the batteries.

The flight may be safely continued even with one generator offline. Essential systems are still powered for a sufficient time. Non-essential systems are cut off the electric system and will fail now. As soon as the internal backup batteries of the SkyView system are discharged, there is no PFD or EMS available anymore.

Due to the generator failure, the full power of the electric system is not available anymore and the aircraft batteries will discharge. As soon as these batteries are fully discharged, the entire avionic system incl. radio. This does impede safe continuation of flight, but makes any contact with ATC impossible. Depending on the actual situation, additional electric consumers may be switched off by releasing its circuit breaker to save electric energy.

After a double generator failure, the aircraft is not fed with electric energy anymore. In such a situation, all systems are powered by the aircraft batteries only.

WARNING

Double generator failure leads to engine failure. Engine restart is possible. Remaining flight time is not more than 30min. Thereafter the engine will definitely and finally quit.

3 Emergency Procedures

3.29 misc. Engine Trouble Procedure

- | | | |
|----|---------------------------------|-----------------|
| 1. | AVIATE – NAVIGATE – COMMUNICATE | |
| 2. | landing site | IDENTIFY |
| 3. | emergency switch | LIFT and ENGAGE |
| 4. | SkyView LH | press STAY ON |
| 5. | landing light | OFF |
| 6. | troubleshooting | SEE TABLE |

| | |
|------|---|
| NOTE | <p>By engaging the emergency mode non-essential systems are switched off, i.e.:</p> <ul style="list-style-type: none">• SkyView (has internal backup battery)• NAV lights and strobes• Autopilot• Second COM• 12 V receptacle <p>Selecting STAY ON on the SkyView keeps the system powered on internal backup batteries. Switching on or off the SkyView system is done by pressing the left softkey. It is recommended to have only one SkyView switched on at a time.</p> |
|------|---|

| | |
|------|---|
| NOTE | <p>In case a generator failure can be excluded, the emergency switch may be deactivated at safe altitude.</p> |
|------|---|

| | |
|------|--|
| NOTE | <p>LANE RESET in the following table means to switch off the affected LANE (flashing or permanent warning light) and after a couple of seconds to switching it on again.</p> |
|------|--|

3 Emergency Procedures

| LANE fault | procedure |
|---------------------------------------|--|
| one LANE flashing | <div><div>1. LANE</div><div>RESET</div><div>2. distress solved</div><div>CONTINUE FLIGHT</div><div>3. Flight may be continued to suitable destination on own discretion with one corrupt LANE.</div></div> |
| both LANES flashing | <div><div>1. LANE A</div><div>RESET</div><div>2. LANE B</div><div>RESET</div><div>3. distress solved</div><div>CONTINUE FLIGHT</div><div>4. one LANE ok</div><div>CONTINUE WITH CASE ABOVE</div><div>5. Two flashing LANES may indicate a generator failure. See relevant procedure.</div></div> |
| one LANE lights up | <div><div>1. LANE</div><div>RESET</div><div>2. distress solved</div><div>CONTINUE FLIGHT</div><div>3. Flight may be continued to suitable destination on own discretion with one corrupt LANE.</div></div> |
| on LANE lights up & one LANE flashing | <div><div>1. LANE A</div><div>RESET</div><div>2. LANE B</div><div>RESET</div><div>3. distress solved</div><div>CONTINUE FLIGHT</div><div>4. one LANE ok</div><div>CONTINUE WITH FIRST CASE ABOVE</div><div>5. Flight may be continued to suitable destination on own discretion with one corrupt LANE.</div></div> |
| both LANES light up | <div><div>1. LANE A</div><div>RESET</div><div>2. LANE B</div><div>RESET</div><div>3. distress solved</div><div>CONTINUE FLIGHT</div><div>4. one LANE ok</div><div>CONTINUE WITH FIRST CASE ABOVE</div><div>5. Flight may be continued to suitable destination on own discretion with one corrupt LANE.</div></div> |

3 Emergency Procedures

| | |
|------|---|
| NOTE | One flashing LANE indicates an error with lower severity that has been detected by the internal testing procedures of the ECU and does not imply any risk for an engine failure. |
| NOTE | With one corrupt LANE, the associated engine instruments will fail. This is no reason to be worried. |
| NOTE | Two flashing LANE warning lights indicate an error with lower severity and does not lead to an engine failure. Nevertheless, this might indicate a failure of generator A (the one for the engine systems). The ECU switches to generator B in this case. |

| EMS Messages | procedure |
|--------------------------------|--|
| main fuel pump INOP | 1. main fuel pump FAILED 2. fuel pressure MONITOR 3. continue flight to suitable destination for troubleshooting |
| Voltage indication RED | 1. generator B FAILED 2. continue flight to suitable destination for troubleshooting |
| temp/pressure out of limits | 1. power ADJUST 2. in case alarm does not vanish, continue flight to suitable destination for troubleshooting |

3 Emergency Procedures

3.30 Flight with ONE deactivated LANE Briefing

The engine is equipped with a dual lane engine control unit. Failure of one of those lanes does not lead to an engine failure and does not lead into an immediate dangerous situation.

Once one lane has failed, the associated engine instruments will fail as well. This is no reason to be worried.

In case the engine is operated on one lane only, the POWER mode is activated, meaning: the engine is now fed with a rich fuel to air mixture. This leads to higher fuel consumption and by this to reduced range. An increase of 30% in fuel consumption compared to the values given in section 5 has to be taken into account.

Flight may be continued to a suitable destination to troubleshoot the system.

3.31 Flight with ONE INOP Fuel Pump Briefing

The engine is equipped with two redundant fuel pumps. In case the MAIN pump fails, the system automatically switches to the AUX pump. This is indicated by a warning light in the EMS page of the SkyView system.

With one fuel pump inoperative the engine is operated without limitations. However, redundancy for a vital engine system is not given anymore. Continue flight for landing on suitable destination.

3 Emergency Procedures

3.32 Precautionary Landing Procedure

- | | |
|--|--|
| 1. AVIATE – NAVIGATE – COMMUNICATE | |
| 2. landing site | IDENTIFY |
| 3. direction of wind | IDENTIFY |
| 4. landing direction | INTO THE WIND or UPHILL |
| 5. landing site inspection | PERFORM LOW APPROACH |
| 6. approach airspeed | $V_{APP} = 60 \text{ KIAS}$ |
| 7. max. flap speed | $V_{FE} = 78 \text{ KIAS}$ |
| 8. declare emergency | OWN DISCRETION |
| 9. safety belts | TIGHTEN |
| 10. flaps | DOWN |
| 11. landing light | RECOMMENDED |
| 12. engine power | AS REQUIRED |
| 13. elevator trim | AS REQUIRED |
| 14. CHT | max. $248^{\circ}\text{F} = 120^{\circ}\text{C}$ |
| 15. oil temperature | $120...266^{\circ}\text{F} = 50...130^{\circ}\text{C}$ |
| 16. touch down on main wheels first with min. airspeed | |
| 17. brakes | AS REQUIRED |
| 18. ignition key | OFF |
| 19. recovery system | SECURED |
| 20. parking brake | SET |

3 Emergency Procedures

3.33 Emergency Landing on Land Procedure

1. AVIATE – NAVIGATE – COMMUNICATE
2. landing site IDENTIFY
3. direction of wind IDENTIFY
4. approach airspeed $V_{APP} = 60$ KIAS
5. max. flap speed $V_{FE} = 78$ KIAS
6. flaps DOWN
7. trim AS REQUIRED
8. declare emergency MAYDAY MAYDAY MAYDAY
9. ignition key OFF
10. safety belts TIGHTEN
11. landing direction INTO THE WIND
or UPHILL
12. touchdown with full elevator on main wheels first
13. after landing, release safety belts and vacate aircraft

3.34 Emergency Landing on Water Procedure

1. AVIATE – NAVIGATE – COMMUNICATE
2. direction of wind IDENTIFY
3. approach airspeed $V_{APP} = 60$ KIAS
4. max. flap speed $V_{FE} = 78$ KIAS
5. flaps DOWN
6. trim AS REQUIRED
7. declare emergency MAYDAY MAYDAY MAYDAY
8. ignition key OFF
9. safety belts TIGHTEN
10. doors JETTISON
11. touchdown with full elevator on water surface
12. after landing release safety belts and vacate aircraft

4 Standard Procedures

Table of Content

| sect. | description | page |
|-------|-------------------------------------|------|
| 4.1 | Definitions | 4-2 |
| 4.2 | Preflight Check | 4-3 |
| 4.3 | Before Start-Up | 4-4 |
| 4.4 | Engine Start | 4-6 |
| 4.5 | After Start-Up | 4-7 |
| 4.6 | Engine Run Up | 4-7 |
| 4.7 | Taxi | 4-8 |
| 4.8 | Departure | 4-8 |
| 4.9 | Take-Off | 4-9 |
| 4.10 | Best Angle of Climb Speed (V_x) | 4-12 |
| 4.11 | Best Rate of Climb Speed (V_y) | 4-12 |
| 4.12 | Cruise | 4-12 |
| 4.13 | Flying in Rain | 4-13 |
| 4.14 | Recovery from Stall | 4-13 |
| 4.15 | Flying Without Doors | 4-14 |
| 4.16 | Descent | 4-15 |
| 4.17 | Approach | 4-15 |
| 4.18 | Landing | 4-16 |
| 4.19 | Balked Landing | 4-18 |
| 4.20 | After Landing | 4-18 |
| 4.21 | Shutdown | 4-18 |

4 Standard Procedures

4.1 Definitions

Procedures

are instructions that must be performed in the given sequence, as far as possible without interruption.

Checklists

are lists for items to be checked in the appropriate phase of flight (taxi, take-off, climb, etc.). Timing and sequence of the steps to be executed may vary according to the individual flight.

Briefings

are guidelines for upcoming procedures. With the help of briefings, the pilot and passenger should recapitulate those procedures.

4 Standard Procedures

4.2 Preflight Check

Checklist


Checks outside the aircraft

1. fuel system drained before moving the aircraft at all
2. engine oil level (between min. and max. markings)
3. level of engine coolant (between min. and max. markings)
4. cowling is closed and properly secured
5. propeller has no damage or wear
6. nose gear and wheel/tire have no damage or wear, air pressure is correct and suspension is free
7. static port is clean
8. main wing bolt properly secured with Fokker needle
9. pitot tube is clean and properly fixed
10. wingtip and cover glass are securely mounted and not damaged
11. aileron, linkage and hinges have free travel and no damage, counterweights are securely fixed
12. upper wing strut attachment is secured
13. flap, linkage and hinges have no damage, rubber stops (flutter damper) on outer hinges are in place
14. lower wing strut attachment is secured
15. belly top antennas are securely mounted and free of damage
16. left main gear and wheel/tire have no damage or wear, air pressure is correct and suspension is free
17. cover of ejection opening has no damage
18. top antennas are securely mounted and free of damage
19. fuselage has no damage
20. horizontal tail, elevator, linkage and hinges have free travel and no damage
21. trim actuator linkage securely mounted and not damaged
22. elevator quick-fastener is securely locked
23. rudder linkage and hinges have free travel and no damage
24. horizontal tail attachment bolts are secured
25. horizontal tail, elevator, linkage and hinges have free travel and no damage

4 Standard Procedures

26. fuselage has no damage
27. right main gear and wheel/tire have no damage or wear, air pressure is correct and suspension is free
28. lower wing strut attachment is secured
29. flap, linkage and hinges have no damage, rubber stops (flutter damper) on outer hinges are in place
30. upper wing strut attachment is secured
31. aileron, linkage and hinges have free travel and no damage, counterweights are securely fixed
32. wingtip and cover glass are securely mounted and not damaged
33. landing light glass is not damaged
34. static port is clean
35. main wing bolt properly secured with Fokker needle


It is suggested to perform the outside check according to the following flow diagram:




Insecurely connected, improper operation of control surfaces or insecurely locked fasteners will lead to loss of control of the aircraft!!

4 Standard Procedures

Checks inside the aircraft

- 
1. aileron quick-fasteners are securely locked
 2. enough fuel on board for the flight
 3. both seats are properly secured in intended position
 4. both doors can be locked
 5. check proper functioning of the flap drive and gauge



Insecurely connected, improper operation of control surfaces or insecurely locked fasteners will lead to loss of control of the aircraft!!

4 Standard Procedures

4.3 Before Start-Up

Checkliste

- | | |
|--------------------|----------|
| 1. doors | LOCKED |
| 2. safety belts | FASTENED |
| 3. parking brake | SET |
| 4. recovery system | ARMED |

4.4 Engine Start

Procedure

- | | |
|-----------------|------------------------|
| 1. ignition key | AVIONIC |
| 2. avionics | SET UP (if applicable) |
| 3. ignition key | ENGINE |
| 4. engine power | CRACKED OPEN |
| 5. propeller | FREE |
| 6. engine start | START |

NOTE

As long as the engine is not running, engine instrumentation is offline. They become online as soon as the engine is running.

NOTE

It is not required to switch off avionics during engine start. Once the START button has been hit, they are shed from the engine starter circuit and are thereby protected against overvoltage.

NOTE

Once the START button has been hit, the start procedure is performed automatically. After app. 3 seconds the starter engine is engaged and the propeller starts turning. To interrupt the start-up procedure, turn ignition key onto position AVIONIC or OFF.

4 Standard Procedures

4.5 After Start-Up Procedure

1. oil pressure OK
2. engine speed for warm-up 2,000 ... 2,500 rpm

| | |
|-------------|---|
| NOTE | Once the engine has started it is supported by generator B, the aircraft systems are powered by the aircraft batteries only. Once engine speed is above 2,500 rpm for at least 5 seconds, electric supply for the engine is switched to generator A and the aircraft systems are powered by generator B. Avoid longer operation without having switched the generators. |
|-------------|---|

| | |
|-------------|--|
| NOTE | Warming up the engine works best with engine speeds below 2,500 rpm. Higher engine speeds improve cooling and therefore increases time to warm up the engine and stress on the engine. |
|-------------|--|

4.6 Engine Run Up Checklist

1. oil temperature min. 50°C / 120°F
2. engine speed 4,000 rpm
3. engine TEST TEST
4. LANE check max. 180 rpm DROP
5. main fuel pump INOP WARNING COMES UP
6. main fuel pump INOP WARNING LAPSES
7. engine speed IDLE

| | |
|-------------|--|
| NOTE | Usually a slight increase in engine speed is observed instead of a decrease in engine speed. |
|-------------|--|

4 Standard Procedures

4.7 Taxi Procedure

- | | |
|----------------------|-----------------|
| 1. landing light | RECOMMENDED |
| 2. parking brake | RELEASE |
| 3. engine speed | AS REQUIRED |
| 4. control on ground | VIA PEDALS |
| 5. min. turn radius | ca. 20 ft = 7 m |
| 6. braking | AS REQUIRED |
| 7. taxi speed | APPROPRIATE |

4.8 Departure Briefing

- | | |
|------------------------------|----------------------|
| 1. wind, weather, visibility | OK |
| 2. ATIS | CHECKED |
| 3. runway | CORRECT DIRECTION |
| 4. traffic pattern | ALTITUDE and ROUTING |

4 Standard Procedures

4.9 Take-Off Procedure

standard take-off

- | | |
|------------------------|-------------------------|
| 1. brakes | SET |
| 2. flaps | UP |
| 3. elevator trim | GREEN MARK ON INDICATOR |
| 4. rudder and aileron | NEUTRAL |
| 5. engine power | FULL POWER |
| 6. brakes | RELEASE |
| 7. rotate and lift-off | 52 KIAS |
| 8. initial climb speed | 57 KIAS |
| 9. best climb | 60 KIAS |

NOTE

Take-off distances given in chapter 5 have been determined with this procedure. Take-off distance varies significantly with precise handling and condition of the runway.

NOTE

Take-off with reduced power is possible, though not recommended. No take-off shall be performed with engine speed lower than 4,500 rpm. A drastically reduced take-off performance must be taken into account.

NOTE

Engine speed prior to take-off run is app. 5,200 rpm.

4 Standard Procedures

comfort take-off

- | | |
|-----------------------|-------------------------|
| 1. flaps | UP |
| 2. elevator trim | GREEN MARK ON INDICATOR |
| 3. rudder and aileron | NEUTRAL |
| 4. engine power | FULL POWER |
| 5. rotate | 45 kIAS |
| 6. lift-off | 50 ... 55 kIAS |
| 7. best climb | 60 kIAS |

NOTE

Take-off with this procedure is way more comfortable, but take-off distances increase significantly as when using standard take-off procedure.

NOTE

Take-off with reduced power is possible, though not recommended. No take-off shall be performed with engine speed lower than 4,500 rpm. A drastically reduced take-off performance must be taken into account.

NOTE

Engine speed prior to take-off run is app. 5,200 rpm.

4 Standard Procedures

short/soft field take-off

- | | |
|------------------------|-------------------------|
| 1. brakes | SET |
| 2. flaps | 15 deg |
| 3. elevator trim | GREEN MARK ON INDICATOR |
| 4. rudder and aileron | NEUTRAL |
| 5. engine power | FULL POWER |
| 6. brakes | RELEASE |
| 7. rotate and lift off | 50 kIAS |
| 8. initial climb speed | 52 kIAS |
| 9. retract flaps | SAFE ALTITUDE |
| 10. best climb | 60 kIAS |

NOTE

When using the short/soft field take-off procedure, take-off with reduced power is not permitted.

NOTE

Engine speed prior to take-off run is app. 5,200 rpm.

4 Standard Procedures

4.10 Best Angle of Climb Speed (V_x) Checklist

- | | |
|------------------------|--------------------------|
| 1. flaps | 15deg or CLEAN |
| 2. steepest climb | $V_x = 50$ kIAS |
| 3. engine power | FULL POWER |
| 4. coolant temperature | max. 248°F = 120°C |
| 5. oil temperature | 120...266°F = 50...130°C |

NOTE

Best angle of climb is achieved with flaps 15deg.

4.11 Best Rate of Climb Speed (V_y) Checklist

- | | |
|------------------------|--------------------------|
| 1. flaps | CLEAN |
| 2. best climb | $V_y = 60$ kIAS |
| 3. engine power | FULL POWER |
| 4. coolant temperature | max. 248°F = 120°C |
| 5. oil temperature | 120...266°F = 50...130°C |

4.12 Cruise Checklist

- | | |
|--------------------------------------|--|
| 1. flaps | CLEAN |
| 2. landing light | ON (recommended) |
| 3. engine speed | AS REQUIRED |
| 4. operating maneuvering speed V_o | = 88 kIAS (600kg AUW) = 59 kIAS (400kg AUW) |
| 5. normal operating speed | $V_{NO} = 107$ kIAS |
| 6. never exceed speed | $V_{NE} = 135$ kIAS |
| 7. max. cont. engine speed | 5,500 rpm |
| 8. coolant temperature | max. 248°F = 120°C |
| 9. oil temperature | 120...266°F = 50...130°C |

4 Standard Procedures

4.13 Flying in Rain

Checklist

- | | |
|------------------------|--------------------------|
| 1. engine speed | AS REQUIRED |
| 2. coolant temperature | max. 248°F = 120°C |
| 3. oil temperature | 120...266°F = 50...130°C |

NOTE

- visibility to the front is very limited
- windscreen may need defogging
- flight performance is reduced
- fuel consumption increases
- stall speed increases
- braking efficiency during landing is reduced

4.14 Recovery from Stall

Procedure

- | | |
|------------------------|------------------|
| 1. stick back pressure | RELEASE |
| 2. rudder | OPPOSITE to BANK |
| 3. aileron | NEUTRAL |
| 4. engine power | AS REQUIRED |

4 Standard Procedures

4.15 Flying Without Doors Procedure

- | | |
|-----------------------|--------------------|
| 1. door lock | OPEN |
| 2. gas spring on door | DETACH |
| 3. hinge pin | PULL |
| 4. door | TAKE OUT CAREFULLY |

| | |
|-------------|---|
| NOTE | V _{NE} is reduced to 100 kIAS when flying without doors. |
|-------------|---|

| | |
|-------------|--|
| NOTE | Flying without doors leads to high wind velocities inside the cabin. |
|-------------|--|

| | |
|-------------|--|
| NOTE | For flight without doors, either one door or both doors must be taken out before flight. |
|-------------|--|

| | |
|-------------|--|
| NOTE | Unlocking and opening doors in flight is prohibited. |
|-------------|--|

It is not required to prepare a separate weight and balance report and/or equipment list for operation without doors in case the detachment of the door(s) has been taken into consideration during flight preparation. A logbook entry is not required after the door(s) have been taken out or installed again.

Following data shall be used for the flight's individual weight and balance:

| | | | | |
|-----------------|---------|---|---------|--------|
| weight of door | 3,350 g | = | 7.7 lbs | (each) |
| station of door | 150 mm | = | 5.9 in | |

4 Standard Procedures

4.16 Descent

Checklist

- | | |
|--------------------------------------|--|
| 1. flaps | CLEAN |
| 2. engine speed | AS REQUIRED |
| 3. operating maneuvering speed V_O | = 88 kIAS (600kg AUW) = 59 kIAS (400kg AUW) |
| 4. normal operating speed | V_{NO} = 107 kIAS |
| 5. never exceed speed | V_{NE} = 135 kIAS |
| 6. max. cont. engine speed | 5,500 rpm |
| 7. coolant temperature | max. 248°F = 120°C |
| 8. oil temperature | 120...266°F = 50...130°C |

4.17 Approach

Checklist

- | | |
|------------------------------|----------------------|
| 1. wind, weather, visibility | OK |
| 2. ATIS | CHECKED |
| 3. runway | CORRECT DIRECTION |
| 4. traffic pattern | ALTITUDE and ROUTING |
| 5. radios | ON and FREQUENCY SET |
| 6. transponder | AS REQUIRED |
| 7. full flaps airspeed | V_{FE} = 78 kIAS |
| 8. approach airspeed | V_{APP} = 60 kIAS |
| 9. flaps | AS REQUIRED |
| 10. landing light | RECOMMENDED |

NOTE

In windy and gusty conditions increase approach airspeed as appropriate and take care for increased landing distances.

4 Standard Procedures

4.18 Landing Procedure

1. full flaps airspeed

$V_{FE} = 78$ KIAS
2. approach airspeed

$V_{APP} = 60$ KIAS
3. flaps

DOWN
4. target airspeed

AS RECOMMENDED
5. engine power

AS REQUIRED
6. elevator trim

AS REQUIRED
7. touch down on main wheels first
8. brakes

IMMEDIATELY

The target airspeed (airspeed on short final, app. 50ft above threshold) differs with actual aircraft weight. Please refer to the following table to select the correct approach airspeed.

| aircraft weight | recommended target airspeed |
|-----------------|-----------------------------|
| 1,000 lb | 45 KIAS |
| 1,100 lb | 47 KIAS |
| 1,200 lb | 50 KIAS |
| 1,320 lb | 52 KIAS |

| | |
|------|---|
| NOTE | Landing distances given in chapter 5 have been determined with approach airspeeds given above. Landing with partial flaps or clean is possible and permitted, but landing distance will be significantly longer due to higher approach speeds required by higher stall speed. |
|------|---|

| | |
|------|---|
| NOTE | In high wind or gusty conditions less than full flap setting or clean flaps might be appropriate. |
|------|---|

4 Standard Procedures

advise

In landing configuration, the airplane is very draggy and the propeller provides additional braking. Therefore, airspeed bleeds off quickly during flare.

It is easy to misjudge altitude during flare. When flare is initiated too high and airspeed bleeds away the airplane may stall or bounce.

In doubt or without an urge to achieve shortest landing distance as possible, keep a higher target airspeed.

rule of thumb

Keep it at sixty knots!
Or use all your guts.

4 Standard Procedures

4.19 Balked Landing Procedure

- | | |
|------------------------|---------------|
| 1. engine power | FULL POWER |
| 2. initial climb | 52 kIAS |
| 3. flaps retract | SAFE ALTITUDE |
| 4. best climb | 60 kIAS |
| 5. coolant temperature | max. 120°C |
| 6. oil temperature | 50...130°C |

4.20 After Landing Checklist

- | | |
|--------------------------|-------------|
| 1. landing light | RECOMMENDED |
| 2. flaps | UP |
| 3. radio and transponder | AS REQUIRED |

4.21 Shutdown Checklist

- | | |
|--------------------|---------|
| 1. landing light | OFF |
| 2. ignition key | OFF |
| 3. recovery system | SECURED |
| 4. parking brake | SET |

NOTE

It is permissible to switch avionics (GPS, radio, transponder, intercom) together with the avionics switch rather than separately.

NOTE

The engine may only be switched off on ground. Engine shut-down in flight is not an approved procedure. Without technical reason (see section 3 – emergency procedures), engine shut-down in flight shall be avoided.

5 Performance

Table of Contents

| sect. | description | page |
|--------------|--------------------------------|-------------|
| 5.1 | General | 5-2 |
| 5.2 | Summary of Flight Performances | 5-3 |
| 5.3 | ISA Atmosphere | 5-4 |
| 5.4 | Take-Off Distance | 5-5 |
| 5.5 | Landing Distance | 5-8 |
| 5.6 | Cruise Speed and Fuel Flow | 5-11 |
| 5.7 | Range and Endurance | 5-12 |
| 5.8 | Rate of Climb | 5-14 |
| 5.9 | Low Airspeed and Stall | 5-16 |
| 5.10 | Safe Glide Ratio | 5-17 |

5 Performance

5.1 General

| | |
|-------------|---|
| NOTE | All flight performances given in this section (speed, range, fuel flow, rate of climb, etc.) are reference values. Tolerances of engine and propeller as well as deviations from standard temperature and density of air may reveal divergent performances. |
| NOTE | <p>Flying without doors reduces flight performance drastically. Effect varies significantly with airspeed. Flying without sideslip has a large impact on flight performance when flying without doors.</p> <p>Longer cross-country flights without doors are not recommended.</p> |
| NOTE | The aircraft may be operated without fairings on wheels and/or landing gear legs or with flight school tires. If not otherwise mentioned, performance is reduced by app. 5% on any of the following criteria: climb, cruise, range |

5 Performance

5.2 Summary of Flight Performances


| | | |
|--|--------|-------|
| V _{SO} (stallspeed flaps 35°) | KLAS | 39 |
| V _{SI} (stallspeed flaps 15°) | KLAS | 40 |
| V _S (stallspeed flaps 0°) | KLAS | 43 |
| V _X (any flap setting) | KLAS | 50 |
| V _Y (flaps clean) | KLAS | 60 |
| rate of climb at MSL flaps clean | ft/min | 710 |
| rate of descent at MSL in idle | ft/min | 520 |
| best glide | KLAS | 60 |
| take-off roll distance (flaps 0°) | ft | 784 |
| take-off air distance | ft | 666 |
| take-off distance | ft | 1,450 |
| take-off roll distance (flaps 15°) | ft | 689 |
| take-off air distance | ft | 459 |
| take-off distance | ft | 1,148 |
| landing air distance (flaps 35°) | ft | 584 |
| landing roll distance | ft | 381 |
| landing distance | ft | 965 |

5 Performance

5.3 ISA Atmosphere

All flight performance data are given for ISA standard atmosphere at sea level and standard temperature. To determine temperature in relation to ISA conditions please refer to the following chart:

ISA std. Temperature



Flight performance can vary significantly due to tolerances, setting of propeller and engine, flight without doors, deviation of temperature and air density from standard ISA conditions, etc.

Range applies to the 22 gallon fuel tank system (21 gallons usable) without reserve, within the ICAO standard atmosphere at given altitude.

5 Performance

5.4 Take-Off Distances

For take-off with max. take-off weight on an even, dry, paved runway with ISA conditions on sea level, dry aircraft, wind calm, standard tires with wheel pants and doors closed the following take-off distances apply:

flaps 0°

| | | |
|------------------------|----|-------|
| take-off roll distance | ft | 784 |
| take-off air distance | ft | 666 |
| take-off distance | ft | 1,450 |

flaps 15°

| | | |
|------------------------|----|-------|
| take-off roll distance | ft | 689 |
| take-off air distance | ft | 459 |
| take-off distance | ft | 1,148 |

| | |
|------|--|
| NOTE | Take-off distances have been determined at ISA standard conditions at mean sea level and over a virtual 50ft obstacle. |
|------|--|

| | |
|------|---|
| NOTE | Standard procedures apply. Diverting from the standard procedures defined in section 4 will lead to different take-off distances. |
|------|---|

5 Performance

Performance data apply under ISA conditions on an even, dry, hard runway surface, standard tires with wheel pants and doors closed. Various circumstances have an effect on take-off performance, it is recommended to use following add-ons on roll- and air distances:

| add-ons on take-off roll distance | |
|---|--------------------|
| for dry grass | + 20% |
| for wet grass | + 30% |
| for soft surface | + 60% |
| for flight school tires (main tires 15x6.0-6) | + 5% |
| per 5 knots tailwind component | + 20% |
| per 2% uphill slope | + 10% |
| for high temperatures above standard | + 10% per 10°C |
| for altitude above sea level (density altitude) | + 10% per 1,000 ft |

| add-ons on take-off air distance | |
|---|--------------------|
| for dirty or wet wings | + 30% |
| per 5 knots tailwind component | + 20% |
| for high temperatures above standard | + 10% per 10°C |
| for altitude above sea level (density altitude) | + 10% per 1,000 ft |
| for flight without fairings (main tires 4.00-6) | + 5% |
| for flight school tires (main tires 15x6.0-6) | + 5% |
| for flight without doors | + 10% |

| | |
|-------------|---|
| NOTE | Reduction of take-off distances due to downhill slope or headwind must not be taken into account. |
|-------------|---|

5 Performance

example calculation:

Take-off in 2.000ft at 35°C from wet grass runway, 5kt tailwind, wet wing, take-off with flaps 15°. Standard wheels are mounted with wheel fairings.

| | | |
|----|---------------------------------|------|
| 1. | temperature acc. to ISA diagram | 12°C |
| | real temperature | 30°C |
| | temperature above ISA: | 18°C |
| | add-on for 18°C above ISA | 18% |
| 2. | add-on for 2.000ft | 20% |
| 3. | add-on for tailwind | 20% |
| 4. | add-on for wet grass runway | 30% |
| 5. | add-on for wet wing | 30% |

take-off roll distance = 689ft + 18% (temperature)
+ 20% (altitude)
+ 20% (tailwind)
+ 30% (wet grass runway)
=1,522ft

take-off air distance = 461ft + 18% (temperature)
+ 20% (altitude)
+ 20% (tailwind)
+ 30% (wet wing)
=1,014ft

take-off distance =2,536ft

| | |
|-------------|---|
| NOTE | Take-off distance has more than doubled compared to ideal conditions! |
|-------------|---|

| | |
|-------------|---|
| NOTE | Real-life take-off distance can be even higher. |
|-------------|---|

5 Performance

5.5 Landing Distances

Landing is to be done with full flaps (35 deg). After touchdown, brake to the max for shortest landing distance, but do not block the wheels.

For landing with max. take-off weight on dry, paved runway with ISA conditions on sea level, dry aircraft, wind calm, standard tires with wheel pants and doors closed the following landing distances apply:

Flaps 35°

| | | |
|-----------------------|----|-----|
| landing air distance | ft | 584 |
| landing roll distance | ft | 381 |
| landing distance | ft | 965 |

| | |
|------|---|
| NOTE | Landing distances have been determined at ISA standard conditions at mean sea level and over a virtual 50ft obstacle. |
|------|---|

| | |
|------|--|
| NOTE | Standard procedures apply. Diverting from the standard procedures defined in section 4 will lead to different landing distances. |
|------|--|

5 Performance

Performance data apply under ISA conditions on an even, dry, hard runway surface, standard tires with wheel pants and doors closed. Various circumstances have an effect on take-off and landing performance, it is recommended to use following add-ons on roll- and air distances:

| add-ons on landing roll distance | |
|---|-------------------|
| for dry grass | + 15% |
| for wet grass | + 35% |
| for soft or slippery surface | + 60% |
| for flight school tires (main tires 15x6.0-6) | + 5% |
| per 5 knots tailwind component | + 20% |
| per 2% downhill slope | + 10% |
| for high temperatures above standard | + 5% per 10°C |
| for altitude above sea level (density altitude) | + 5% per 1,000 ft |
| add-ons on landing air distance | |
| for dirty or wet wings | + 30% |
| per 5 knots tailwind component | + 50% |
| for high temperatures above standard | + 5% per 10°C |
| for altitude above sea level (density altitude) | + 5% per 1,000 ft |
| for flight without fairings (main tires 4.00-6) | + 5% |
| for flight school tires (main tires 15x6.0-6) | + 5% |
| for flight without doors | + 10% |

| | |
|-------------|--|
| NOTE | Reduction of landing distances due to uphill slope or headwind must not be taken into account. |
|-------------|--|

5 Performance

example calculation:

Landing on soft surface with 2.000ft field elevation at 22°C, 5kt tailwind, wet wing and 2% downhill slope

- | | |
|------------------------------------|------|
| 1. temperature acc. to ISA diagram | 12°C |
| real temperature | 22°C |
| temperature above ISA: | 10°C |
| add-on for 10°C above ISA | 10% |
| 2. add-on for 2.000ft | 10% |
| 3. add-on for downhill slope | 10% |
| 4. add-on for soft runway | 60% |
| 5. add-on for wet wing | 30% |

landing air distance = 584ft + 10% (temperature)
+ 10% (altitude)
+ 30% (wet wing)
= 919ft

landing roll distance = 382ft + 10% (temperature)
+ 10% (altitude)
+ 10% (slope)
+ 60% (soft runway)
= 811ft


landing distance =1,730ft

| | |
|------|---|
| NOTE | Landing distance has almost doubled compared to ideal conditions! |
|------|---|

| | |
|------|--|
| NOTE | Real-life landing distance can be even higher. |
|------|--|


5 Performance

5.6 Cruise Speed and Fuel Flow




5 Performance

5.7 Range and Endurance




5 Performance



5 Performance

5.8 Rate of Climb



5 Performance

| | | | |
|---|----------------------|------|-----|
| best angle of climb airspeed (any flap setting) | V_x | kIAS | 50 |
| best rate of climb airspeed (flaps clean) | V_y | kIAS | 60 |
| best rate of climb at MSL initial climb | ROC | fpm | 710 |

| | |
|-------------|--|
| NOTE | Climb is flown with flaps retracted, see section 4 |
|-------------|--|

| | |
|-------------|---|
| NOTE | Expect a performance loss of about 5% when flying without wheel fairings. |
|-------------|---|

| | |
|-------------|--|
| NOTE | Expect a performance loss of about 10% when flying without doors |
|-------------|--|

5 Performance

5.9 Low Airspeed and Stall

If the center of gravity is within the permissible range, the aircraft will be fully controllable until reaching the stall speed. As the aircraft approaches the stall speed, this will be indicated by slight aerodynamic buffeting. The stall speed is reached when the aircraft drops the nose or the elevator control comes to a stop. Once stall speed is reached, the pilot should lower the nose of the aircraft to re-establish a safe airspeed. Only release of the back pressure of the elevator is required, a significant “push” input is not required. When stalling the aircraft while in a turn the stall speed will increase.

stall speeds in level flight with engine idle

CG at most forward position

| flap position | deg | 0 | 15 | 35 |
|---------------|------|----|----|----|
| stall speed | klAS | 43 | 40 | 39 |

CG at most rearward position

| flap position | deg | 0 | 15 | 35 |
|---------------|------|----|----|----|
| stall speed | klAS | 42 | 37 | 35 |

Stalling the aircraft with engine at full power and/or in turns is possible and permissible. Expect airspeed indication outside the reliable range of the airspeed indicator. A significant stall break will occur. Without experience a mentionable altitude loss shall be considered for safe recovery.

5 Performance

5.10 Safe Glide Ratio

Airspeed for best glide is 60kIAS. Safe glide ratio of the airplane with wind milling propeller is approximately 1:11. This will result in following glide distances:

| | | |
|-------------------------|----------|--------|
| airspeed for best glide | [kIAS] | 60 |
| glide ratio | [--] | 1 : 11 |
| flaps | [deg] | 0 |

| | | | | | | |
|-------------|--------|-------|-------|-------|-------|--------|
| altitude | [ft] | 2,000 | 4,000 | 6,000 | 8,000 | 10,000 |
| glide range | [nm] | 3.6 | 7.2 | 10.9 | 14.5 | 18.1 |

| | |
|-------------|---|
| NOTE | <p>Glide performance is given for a clean airframe with flaps retracted, airspeed for best glide is 60kIAS.</p> <p>Deflected flaps, dirty airframe or other airspeeds will lead to lower glide ratio.</p> |
|-------------|---|

5 Performance

intentionally left blank

6 Weight and Balance

Table of Contents

| | | |
|------|---|------|
| 6.1 | General | 6-2 |
| 6.2 | Station Definitions | 6-3 |
| 6.3 | Aircraft Weighing Procedure | 6-4 |
| 6.4 | Change of Equipment | 6-5 |
| 6.5 | Operating Weights and Loading | 6-6 |
| 6.6 | Weight and Balance Chart | 6-6 |
| 6.7 | Center of Gravity Range and Determination | 6-7 |
| 6.8 | Calculation Example | 6-8 |
| 6.9 | Equipment List | 6-9 |
| 6.10 | Aircraft Specific Weights | 6-15 |

6 Weight and Balance

6.1 General

This section provides information how to determine the inflight center of gravity. Prior to each take-off, the pilot in command shall ensure that the center of gravity is within its permissible envelope.

For a correct determination of the inflight center of gravity the pilot needs following information:


- weight of pilot
- weight of passenger
- weight of baggage
- weight of fuel on board
- weight and center of gravity of the empty aircraft

The weight and balance report of the empty aircraft (empty CG) shall always be up to date and noted in section 6.7 of this manual. The procedure to determine the empty weight and CG is given in section 6.3 of this manual and in section 1 of the maintenance manual. The empty CG must be updated:

- after significant change of equipment
- after major repair

6 Weight and Balance

6.2 Station Definitions




| item | station |
|---------------------|----------|
| a seats | 210 mm |
| b baggage | 950 mm |
| c fuel | 960 mm |
| x empty/inflight CG | variable |

Procedure for determination of empty CG is given in the maintenance handbook. Actual empty CG can be obtained from the aircraft's individual weight and balance report and/or section 6.8 of this manual.

6 Weight and Balance

6.3 Aircraft Weighing Procedure

To determine the aircraft empty weight and CG, put the aircraft on 3 weighing scales, positioned on a level surface. Before weighing, a level wing main chord has to be established (use pads between main wheels and scale beneath). A check-mark reference point (R.P.) on the leading edge of the left wing, adjacent to the pitot tube, is provided to ease the levelling procedure. To level the wing main chord, use a flexible clear hose, filled with water, as a spirit level.



aircraft empty weight

$$G = G_1 + G_2$$

aircraft empty CG

$$x = \frac{G_2 * b}{G_1 + G_2} - a$$

6 Weight and Balance

6.4 Change of Equipment

After change of equipment with known weight and CG of the added or removed equipment the new empty weight and CG of the aircraft can also be calculated instead of being determined by weighing as follows:

| | |
|------------------------------|-------|
| old empty weight | G_o |
| new empty weight | G_n |
| weight of item added/removed | G_i |
| old empty CG | X_o |
| new empty CG | X_n |
| station item added/removed | X_i |

| | | | |
|------------------|-------|---|-------------|
| new empty weight | G_n | = | $G_o + G_i$ |
|------------------|-------|---|-------------|

| | | | |
|--------------|-------|---|---------------------------------------|
| new empty CG | X_n | = | $\frac{G_o X_o + G_i X_i}{G_o + G_i}$ |
|--------------|-------|---|---------------------------------------|

| | |
|------|--|
| NOTE | Use negative sign of weight for items removed. |
| NOTE | Refer to section 6.9 for stations and weight of equipment items that may be added or removed without re-certification (release to service as per EASA Part-ML still required). |


6 Weight and Balance

6.5 Operating Weights and Loading

The CG range for any given airborne weight, measured from reference, must be within the permissible limits of 9.6in to 16.3in.

| | |
|-------------------------|----------|
| minimum airborne weight | 880 lb |
| maximum take-off weight | 1.320 lb |
| front limit of CG | 9.6 in |
| aft limit of CG | 16.3 in |

6.6 Weight and Balance Chart



6 Weight and Balance

6.7 Center of Gravity Range and Determination

The following procedure must be used to calculate the inflight CG.

1. moment calculation

$$\text{moment (lb-inch)} = \text{weight (lb)} \times \text{station (inch)}$$

| | weight lb | station inch | moment lb-inch |
|----------------------|--------------|----------------------|-------------------|
| empty weight | _____ | _____ | _____ |
| occupants | _____ | 8.3 | _____ |
| Baggage | _____ | 37.4 | _____ |
| fuel | _____ | 37.8 | _____ |
| weight total: | _____ | moment total: | _____ |

2. center of gravity

$$\text{center of gravity (inch)} = \frac{\text{moment total (lb-inch)}}{\text{weight total (lb)}}$$

| | |
|-------------------|---------|
| front limit of CG | 9.6 in |
| aft limit of CG | 16.3 in |

| | |
|-------------|---|
| NOTE | Calculate CG for the entire planned flight. Calculate CG with fuel at take-off and for landing. |
|-------------|---|

| | |
|-------------|---|
| NOTE | Occupants on board shift CG significantly. When filling up the fuel tank, the airplane may tilt on its tail skid. This is acceptable as long as the inflight CG is within limits. |
|-------------|---|

| | |
|----------------|---|
| WARNING | Never fly with an inflight c.g. outside the permitted envelope! |
|----------------|---|

6 Weight and Balance

6.8 Calculation Example

| | weight lb | station inch | moment lb-Inch |
|----------------------|--------------|----------------------|-------------------|
| empty weight | 670 | 12.5 | 8,375 |
| occupants | 175 | 8.3 | 1,453 |
| baggage | 30 | 37.4 | 1,122 |
| fuel | 120 | 37.8 | 4,536 |
| Weight Total: | 995 | Moment Total: | 15,486 |

$$\text{center of gravity (inch)} = \frac{\text{moment total (lb-inch)}}{\text{weight total (lb)}}$$

$$= \frac{15,486 \text{ (lb-inch)}}{995 \text{ (lb)}}$$

$$= 15.6 \text{ inch} \rightarrow \text{OK!}$$

| | |
|-------------|--|
| NOTE | 1 liter of fuel equals 0,72 kg (density of fuel 0,72 kg/ltr) |
|-------------|--|

| | |
|-------------|---|
| NOTE | The example above is given to show how to calculate the center of gravity. Do not use the weights and the empty CG in this example for your own flight preparation. |
|-------------|---|

6 Weight and Balance

6.9 Equipment List

Mooring

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|--------------------------|--------------|------------------|--------|-------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 2 | tie down ring | REMOS | G3-8_WG-04-00-30 | 0.05 | 0.30 | O |
| 2 | Ceiling hanging brackets | REMOS | G3-8_AC-01-00-00 | 0.09 | 0.30 | O |

Venting

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|------------------------|--------------|------------------|--------|-------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | fresh air inlet | REMOS | G3-8_FU-14-00-01 | 0.10 | -0.57 | R |
| 2 | door vents | REMOS | G3-8_FU-11-10-00 | 0.05 | -0.04 | O |
| 2 | windscreen ventilation | REMOS | G3-8_FU-14-00-45 | 0.05 | 0.00 | O |

Cockpit

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|------------------|--------------|------------------|--------|-------|------------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | Instrument Panel | REMOS | G3-8_CP-50-02-00 | 1.50 | -0.35 | R |
| 1 | Seat Belt RH | Schroth | 8-2520M0M0N22-88 | 1.20 | 0.34 | R / O (1*) |
| 1 | Seat Belt LH | Schroth | 8-2620M0M0N22-88 | 1.20 | 0.34 | R / O (1*) |
| 1 | Seat RH std. | REMOS | G3-8_SE-00-00-01 | 1.7 | 0.28 | R / O (1*) |
| 1 | Seat LH std. | REMOS | G3-8_SE-00-00-02 | 1.7 | 0.28 | R / O (1*) |
| 1 | Seat RH tall-man | REMOS | G3-8_FU-15-00-04 | 1.7 | 0.31 | A |
| 1 | Seat LH tall-man | REMOS | G3-8_FU-15-00-03 | 1.7 | 0.31 | A |
| 1 | Seat RH deluxe | REMOS | G3-8_SE-00-00-01 | 2.1 | 0.28 | A |
| 1 | Seat LH deluxe | REMOS | G3-8_SE-00-00-02 | 2.1 | 0.28 | A |

(*) R = required, O = optional, A = alternative

(1*) One seat plus belonging seat belt is required, either LH or RH; 2nd one is optional

6 Weight and Balance

Cockpit cont'd.

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|--------------------------|-----------------|------------------|--------|--------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | Seat RH tall-man deluxe | REMOS | G3-8_FU-15-00-04 | 2.1 | 0.31 | A |
| 1 | Seat LH tall-man deluxe | REMOS | G3-8_FU-15-00-03 | 2.1 | 0.31 | A |
| 1 | Door pocket LH | REMOS | 102754 | 0.2 | 0.20 | O |
| 1 | Door pocket RH | REMOS | 102755 | 0.2 | 0.20 | O |
| 1 | Sidewall fairing LH | REMOS | 102756 | 0.1 | 0.00 | O |
| 1 | Sidewall fairing RH | REMOS | 102757 | 0.1 | 0.00 | O |
| 1 | Baggage compartment | REMOS | 700181 & 700173 | 2.3 | 0.96 | O |
| 2 | Baggage nets | REMOS | 101092 | 0.2 | 0.70 | O |
| 2 | Sun visors | REMOS | G3-8_FU-19-00-00 | 0.7 | 0.05 | O |
| 1 | Baggage carpet std. LH | REMOS | 102762 | 0.1 | 0.70 | O |
| 1 | Baggage carpet std. RH | REMOS | 102763 | 0.1 | 0.70 | O |
| 1 | Baggage carpet del. LH | REMOS | 102768 | 0.1 | 0.70 | O |
| 1 | Baggage carpet del. RH | REMOS | 102769 | 0.1 | 0.70 | O |
| 1 | Floor carpet std. LH | REMOS | 102787 | 0.6 | - 0.35 | O |
| 1 | Floor carpet std. RH | REMOS | 102788 | 0.6 | - 0.35 | O |
| 1 | Floor carpet del. LH | REMOS | 102766 | 0.6 | - 0.35 | O |
| 1 | Floor carpet del. RH | REMOS | 102767 | 0.6 | - 0.35 | O |
| 1 | Interior Pad ctr. LH | REMOS | 102770 | 0.15 | - 0.30 | O |
| 1 | Interior Pad ctr. RH | REMOS | 102771 | 0.15 | - 0.30 | O |
| 1 | Interior Pad leg area LH | REMOS | 102772 | 0.1 | - 0.30 | O |
| 1 | Interior Pad leg area RH | REMOS | 102773 | 0.1 | - 0.30 | O |
| 1 | Interior Pad armrest | REMOS | 102774 | 0.2 | 0.30 | O |
| 1 | Interior Pad spar | REMOS | 102775 | 0.3 | 0.30 | O |
| 1 | Interior pad rear wall | REMOS | 102776 | 0.4 | 1.25 | O |
| 1 | First-aid kit | various | DIN 13164 | 0.50 | 0.15 | O |
| 1 | Fire extinguisher | AirTotal (o.e.) | Halon | 2.20 | 0.15 | O |

(*) R = required, O = optional, A = alternative

6 Weight and Balance

Electrics

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|------------------------|---------------|------------------|--------|--------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 2 | battery, min. 8.3Ah | not specified | lead battery | 4.20 | - 0.66 | R |
| 2 | battery, min. 8.3Ah | not specified | LiFePO4 battery | 1.60 | - 0.66 | A |
| 1 | Electrical System GXis | REMOS | G3-8_CP-30-06-24 | 8.50 | -0,45 | R |

Emergency Equipment

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|-------------------------------|--------------|-----------------|--------|--------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | ELT | Kannad | 406AF Compact | 1.40 | 0.90 | O |
| 1 | Antenna ELT | RAMI | AV-300 | 0.15 | 1.41 | O |
| 1 | Traffic Alerting System | Garrecht | TRX-1500A | 0.15 | - 0.25 | O |
| 1 | ADS-B-in Antenna for TRX1500A | Air-Store | comes in bundle | 0.15 | -0.35 | O |
| 1 | FLARM Antenna for TRX1500A | Air-Store | GAV-868 | 0.15 | 0.00 | O |

Flight Control System

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|--------------------------|--------------|------------------|--------|-------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 2 | stick grip w/ cooley-hat | Ray Allen | G303 | 0.20 | 0.00 | R |
| 1 | Flap Actuator | LINAK | LA 12 | 0.45 | 0.90 | R |
| 1 | Elevator Trim Actuator | Ray Allen | T2-10A-TS | 0.15 | 4.70 | R |
| 1 | Throttle | REMOS | G3-8_FU-21-00-00 | 0.30 | 0.05 | R |

(*) R = required, O = optional, A = alternative

6 Weight and Balance

Fuel System

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|-------------|--------------|------------------|--------|-------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | Fuel Tank | REMOS | G3-8_FU-22-04-05 | 4.90 | 0.96 | R |
| 1 | Fuel System | REMOS | G3-8_EN-22-05-00 | 2.60 | 0.96 | R |

Landing Gear

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|--------------------------|--------------|------------------|--------|--------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 2 | Main Gear Tires | diverse | 4.00-6/8PR | 2.90 | 0.65 | R |
| 2 | Main Wheel Tubes | diverse | 4.00-6 | 0.35 | 0.65 | R |
| 2 | Brake Assy | REMOS | G3-8_MG-30-00-00 | 0.60 | 0.65 | R |
| 2 | Brake Disk | REMOS | G3-8_MG-10-01-00 | 0.35 | 0.65 | R |
| 1 | Master Brake Cylinder | REMOS | G3-8_FU-21-03-00 | 0.60 | 0.35 | R |
| 6 | Brake Adaptor Kit | REMOS | G3-8_MG-10-30-00 | 0.02 | 0.65 | R |
| 1 | Main Wheel Assy | REMOS | G3-8_MG-10-10-00 | 1.15 | 0.65 | R |
| 1 | Nose Wheel Assy | REMOS | G3-8_NG-50-10-00 | 0.45 | - 0.75 | R |
| 1 | Maingear bellyfairing LH | REMOS | G3-8_MG-40-02-29 | 0.30 | 0.65 | O |
| 1 | Maingear bellyfairing RH | REMOS | G3-8_MG-40-02-28 | 0.30 | 0.65 | O |
| 1 | Maingear legfairing LH | REMOS | G3-8_MG-40-02-25 | 0.25 | 0.65 | O |
| 1 | Maingear legfairing RH | REMOS | G3-8_MG-40-02-24 | 0.25 | 0.65 | O |
| 1 | Maingear Edgefairing LH | REMOS | G3-8_MG-40-02-23 | 0.15 | 0.65 | O |
| 1 | Maingear Edgefairing RH | REMOS | G3-8_MG-40-02-21 | 0.15 | 0.65 | O |
| 1 | Main Gear Fairing LH | REMOS | G3-8_MG-40-02-22 | 0.55 | 0.65 | O |
| 1 | Main Gear Fairing RH | REMOS | G3-8_MG-40-02-20 | 0.55 | 0.65 | O |
| 1 | Nose Gear Fairing | REMOS | G3-8_NG-02-00-00 | 0.60 | - 0.75 | O |

(*) R = required, O = optional, A = alternative

6 Weight and Balance

Lights

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|----------------------|--------------|---------------|--------|--------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | ACL/NAV Light LH | AeroLEDs | PULSAR-NS180 | 0.12 | 0.10 | O |
| 1 | ACL/NAV Light RH | AeroLEDs | PULSAR-NS 180 | 0.12 | 0.10 | O |
| 1 | ACL/Tailight | AeroLEDs | Suntail | 0.09 | 4.70 | O |
| 1 | Landing Light | AeroLEDs | AeroSUN | 0.35 | 0.05 | O |
| 5 | Cockpit Illumination | various | LED-5000MCD | 0.01 | - 0.23 | O |

Flight Instruments and Engine Indication

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|---------------------------|-----------------|---------------|--------|--------|------------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | SkyView Screen LH 10" | DYNON | SV-D1000/T | 1.50 | -0,25 | R / O (2*) |
| 1 | SkyView Screen RH 10" | DYNON | SV-D1000/T | 1.50 | -0,25 | O / R (2*) |
| 1 | SkyView ADAHRS | DYNON | SV-ADAHRS-200 | 0.20 | - 0.25 | R |
| 1 | SkyView EMS | DYNON | SV-EMS-221 | 0.29 | - 0.25 | R |
| 1 | SkyView Battery LH | DYNON | SV-BAT-320 | 0.40 | - 0.25 | R / O (3*) |
| 1 | SkyView Battery RH | DYNON | SV-BAT-320 | 0.40 | - 0.25 | O / R (3*) |
| 1 | SkyView pitot tube | DYNON | 100532-000 | 0.10 | -0.05 | R |
| 1 | SkyView GPS | DYNON | SV-GPS-250 | 0.20 | - 0.25 | O |
| 2 | SkyView ARINC Adapter | DYNON | SV-ARINC-429 | 0.18 | -0.25 | O |
| 1 | OAT Sensor | DYNON | 100433-000 | 0.05 | 0.65 | O |
| 1 | Airspeed Indicator 2-1/4" | Winter (o.e.) | 7 FMS 2 | 0.15 | - 0.25 | O / R (4*) |
| 1 | Altimeter 2-1/4" | Winter (o.e.) | 4 FGH 40 | 0.20 | - 0.25 | O / R (4*) |
| 1 | Compass | Airpath (o.e.) | C-2400 | 0.15 | - 0.25 | O |
| 1 | Compass | Hamilton (o.e.) | PAI-700 | 0.15 | - 0.25 | O |

(*) R = required, O = optional, A = alternative

(2*) Either one of the 2 screens needs to be operational, the 2nd one is optional

(3*) directly linked to the SkyView-screen

(4*) analogue back-up instruments, required when both screens are inop.

6 Weight and Balance

Avionics and Navigation

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|--------------------|--------------|----------------|--------|-------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | XPDR | Garmin | GTX33x series | 1.295 | -0.25 | O |
| 1 | Blind Encoder | TCI | SSD120-RS232 | 0.15 | -0.25 | O |
| 1 | WAAS GPS/NAV/COM | Garmin | GTN750 | 4.24 | -0.25 | O |
| 1 | Audio / Intercom | Garmin | GMA35 / GMA35c | 1.10 | -0.25 | O |
| 1 | Antenna COM | Comant | CI122 | 0.30 | 0.29 | O |
| 1 | Antenna COM | RAMI | AV-17 | 0.30 | 0.29 | A |
| 1 | Antenna NAV | Comant | CI157P | 0.35 | 4.10 | O |
| 1 | Antenna NAV | RAMI | AV-525 | 0.35 | 4.10 | A |
| 1 | Antenna XPDR | RAMI | AV-22 | 0.10 | 1.41 | O |
| 1 | Antenna XPDR | Comant | CI-101 | 0.10 | 1.41 | A |
| 1 | Antenna MKR | Comant | CI-102 | 0.35 | -0.23 | O |
| 1 | Antenna MKR | RAMI | AV-64 | 0.35 | -0.23 | A |
| 1 | Antenna GPS Garmin | Garmin | GA35 | 0.10 | -0.40 | O |

Engine and Propeller

| Qty. | Item | Manufacturer | Model | Weight | Arm | R/O/A (*) |
|-------|-------------------------|--------------|-----------------------|--------|-------|-----------|
| [-] | [-] | [-] | [-] | [kg] | [m] | [-] |
| 1 | Engine (5*) | ROTAX | 912 iSc Sport | 70.07 | -1.01 | R |
| 4 | Shock Mounts | LORD | J 3608 | 0.10 | -0.79 | R |
| 1 | Propeller incl. Spinner | Duc Hélices | FLASH-R H-FSH_3-D-R-I | 6.10 | -1.35 | R |
| 1 | Cooling System | REMOS | G3-8_EN-23-00-09 | 4.50 | -1.10 | R |
| 1 | Exhaust System | CKT | 87-2231 | 5.20 | -0.86 | R |

(*) R = required, O = optional, A = alternative

(5*) engine including overload clutch, starter relay, starter engine, cooling hoses, expansion tank and coolant overflow bottle, oil bottle, oil hoses, firewall-forward fuel hoses, fire protection hoses, ECU, fuse box, fuel pump unit, wiring, cylinder cooling hood, exhaust system incl. muffler & downwind pipes and engine support frame

6 Weight and Balance

6.10 Aircraft Specific Weights

Below are noted the aircraft specific data. Pilots must use this information to ensure a correct weight and balance calculation prior to every flight. This is essential for safe flight. For detailed information of the weight and balance data and the equipment installed on the aircraft refer to the individual aircraft weight and balance report, which includes the equipment list.

| | | | | | | |
|---------------------------|--|--|--|--|--|--|
| sign | | | | | | |
| date of list of equipment | | | | | | |
| date of weighing | | | | | | |
| C.G. | | | | | | |
| payload | | | | | | |
| empty weight | | | | | | |

6 Weight and Balance

intentionally left blank

7 Airplane and Systems Description

Table of Contents

| sect. | description | pages |
|-------|-----------------------------------|-------|
| 7.1 | General | 7-2 |
| 7.2 | Airframe | 7-2 |
| 7.3 | Control System | 7-8 |
| 7.4 | Cockpit Overview | 7-12 |
| 7.5 | DYNON SkyView | 7-14 |
| 7.6 | COM and NAV/COM | 7-19 |
| 7.7 | Intercom and Audio Panel | 7-24 |
| 7.8 | GPS Equipment | 7-26 |
| 7.9 | Transponder | 7-28 |
| 7.10 | GTN750 GPS/NAV/COM/XPDR/Audio | 7-30 |
| 7.11 | Autopilot | 7-33 |
| 7.12 | Electrical System | 7-44 |
| 7.13 | Engine | 7-54 |
| 7.14 | Propeller | 7-60 |
| 7.15 | Throttle and Brakes | 7-61 |
| 7.16 | Flaps | 7-61 |
| 7.17 | Heating and Ventilation | 7-62 |
| 7.18 | Seats | 7-62 |
| 7.19 | Baggage and Luggage | 7-63 |
| 7.20 | Cockpit Lighting | 7-63 |
| 7.21 | External Lights | 7-63 |
| 7.22 | Recovery System | 7-64 |
| 7.23 | Special Equipment and Customizing | 7-65 |

7 Airplane and Systems Description

7.1 General

This section of the POH shall give a brief introduction into the systems installed in the REMOS **GXis**. For further information, maintenance and repair instructions see maintenance manual, latest revision.

7.2 Airframe

Type: Full composite carbon fiber aircraft with two seats.

Design: High wing design with struts, front mounted engine and propeller, traditional stabilizer concept, differential ailerons. Electrically operated flaps (0°, 15°, 35°), electric elevator trim, three-wheel landing gear with steerable nose wheel. Main gear with hydraulic disc brakes. The cabin is equipped with two seats side by side and can be entered and exited by doors on the left and right side of the fuselage.

Layout: Main components are built in half shells from composite fiber material, which are bonded together (carbon fiber, Kevlar and glass fiber).



7 Airplane and Systems Description

assembly of the wing

The wing consists of four main parts: wingbox, flap, aileron and wingtip. The wingtip is bolted to the wingbox, aileron and flap are hinged to allow control movements.


The wing is completed by the cover glass of the landing light and the main wingbolt which attaches the wing to the fuselage. All loads are supported by the wingbolt and the strut.





7 Airplane and Systems Description

structure of the wing

The wingbox is built up by the upper and lower wing skin consisting of CFRP sandwich (foam). Loads are transferred into the main and rear wing spar. The structure is completed by the landing light bay and ribs reinforcing hinge areas, closing the wing to the wingtip and the fuselage.




Ailerons and flaps are built up similarly, consisting of ribs and skins.



7 Airplane and Systems Description

structure of the fuselage

The skins of the fuselage are build of a monolithic layup of glass, carbon and Kevlar, reinforced by carbon tapes. Sandwich material (foam) is found in the fixed surface of the vertical tail only, which is an integral part of the fuselage. The fuselage skin is stiffened by stringers and frames.




7 Airplane and Systems Description

attachment of struts

The wing strut is attached towards the wing and fuselage by a high tensile bolt, which is a genuine REMOS part. The wing strut can pivot about its axis some degree in order to allow the wing to be folded.

The strut consists of a stainless steel tube with fork ends, covered with a fairing made from GFRP.




7 Airplane and Systems Description

installation of horizontal tail

The horizontal tail is made from GFRP. It is built up similar as the wing structure, consisting of ribs and spars.

The elevator included a trim tab, which is operated electrically. The trim tab does not have a dedicated hinge, but uses the elastic flap technology; the upper skin is used as hinge.

Two horns are integral parts of the elevator containing counterweights in order to balance the moving surface.




7 Airplane and Systems Description

7.3 Control System

The control system is made of aluminum pushrods and crank bells for the elevator and aileron controls. The rudder is operated by steel cables. The trim system is an electrically driven trim tab on the elevator; aileron and rudder have ground adjustable tabs.

rudder control system

Rudder control is maintained through use of conventional rudder pedals which also control nose wheel steering. The system is comprised of rudder pedals, a steering rod (sliding translator) towards the nose wheel dip tube, cables and pulleys, all of which link the pedals to the rudder and nose wheel steering.




7 Airplane and Systems Description

elevator control system

The control sticks are installed to a pivoting connection element (stick bridge). Thereby a push/pull input stick is transferred from the control stick through a bell crank and a push-pull tube towards the elevator. An electrical operated elevator trim tab is installed on the elevator.

The elevator control system is connected to the elevator by a quick connector to allow the tailplane to be detached from the aircraft. Checking this quick connector is part of the preflight check!

Insecurely connected, improper operation of control surfaces or insecurely locked fasteners will lead to loss of control of the aircraft!!



7 Airplane and Systems Description

aileron control system

Both control sticks are linked together by a control rod system to ensure synchronous movement. The linkage is located beneath two fiberglass-panels on the floor of the cabin right in front of the seats. A translator connects the control stick linkage to the aileron linkage, which uses several bell cranks to establish the connection to the control surfaces.

The aileron control system is split between the elements installed in the fuselage and in the wing. Both parts are connected by a connector. This connector is a quick connector to allow the wings to be folded. Checking these quick connectors is part of the preflight check!

Insecurely connected, improper operation of control surfaces or insecurely locked fasteners will lead to loss of control of the aircraft!!


Checkers inside the aircraft



7 Airplane and Systems Description

flying with only one control stick installed

Under certain conditions it might be favorable to have only one control stick installed. It is permissible to take out the control stick on the passenger side. See section 2 for the definition of the seat of the pilot in command.



Take out the bolts on the side where the stick shall be uninstalled. Take out the stick. Newer aircraft have the trim and PTT buttons wired with a connector so the stick can be left outside the aircraft. In elder aircraft the stick must be stowed safely. Re-install the mounting ring by means of the bolts.

It is not required to prepare a separate weight and balance report and/or equipment list for operation without the control stick on the passenger side. A logbook entry is not required after the door(s) have been taken out or installed again. Effect on C.G. and weight is neglectable and need not be taken into account.

7 Airplane and Systems Description

7.4 Cockpit Overview

general

The REMOS **GXis** is available with several avionic suites. Standard equipment is one DYNON D600 SkyView SE with 7" screen size and a PS Engineering PAR200A radio with integrated intercom.



Optional equipment is a D700 or HDX800 instead of the D600 screen as well as a second one on the right side of the cockpit. The 10" series consisting of D900 (SkyView SE), D1000/T with optional touchscreen functionality and the HDX1100 are available as well.

The aircraft may also be equipped with a COM or NAV/COM and separate intercom or audio panel instead of the PAR200A. A choice of GPS is available.

Depending on customer's order or certification regulations, mechanical backup may also be installed.

7 Airplane and Systems Description

cockpit examples



7 Airplane and Systems Description

7.5 DYNON SkyView

Versions

The DYNON SkyView Family is available in three versions of two different screen sizes each. The size of the screen has no effect on functionality.


| funktionalität | D600/D900 | D700/D1000 | HDX800/ HDX1100 |
|--------------------------------|-----------|------------|--------------------|
| HD screen | - | - | ● |
| touch screen | - | ○ (*) | ● |
| primary flight instrumentation | ● | ● | ● |
| „six pack“ instrumentation | ● | ● | ● |
| engine instrumentation | ● | ● | ● |
| sectional and approach charts | - | ● | ● |
| synthetic vision | - | ● | ● |
| AoA- and stall-warning | ● | ● | ● |
| G-meter | ● | ● | ● |
| ADSB-out transponder | ● | ● | ● |
| ADSB-in receiver | - | ○ | ○ |
| IFR navigation | - | ○ | ○ |
| timers | - | ● | ● |

- standard
- optional
- not available

(*) available for D1000 only

7 Airplane and Systems Description

screen of DYNON D600/D700/D900/D1000



Figures show elements. Display may vary in flight

7 Airplane and Systems Description

screen of DYNON HDX800/HDX1100



Figure shows elements. Display may vary in flight

primary instrumentation

The primary flight instrumentation and engine indication are realized by the DYNON SkyView glass cockpit system. This is an integrated system, it includes the “Electronic Flight information Display” and the „Multinational Function Display“. Any primary and secondary flight instruments as well as navigation and engine instruments are shown on the screen. This does not include the fuel tank indication. Although such an instrument is integrated into the SkyView, the primary fuel indication is the fuel sight tube behind the right seat.

standby instrumentation

A dedicated airspeed indicator and altimeter may be installed in the left panel, but the primary instrumentation is the DYNON system.

7 Airplane and Systems Description

operation

This POH can only introduce into the very basic operation of the DYNON SkyView System. The avionic system has a very huge functionality and a detailed description will for sure be beyond the scope of this POH.

For further information please refer to the manufacturer's operating instructions that have been handed over together with the aircraft. The website of DYNON www.dynonavinics.com offers a download link for all manuals and their updates.

The offered functionality of the DYNON SkyView is more than offered and used in the **GXiS**. Therefore, it is possible that the DYNON manual references to functionalities that are not implemented into the **GXiS**.

The guaranteed functionality of the DYNON SkyView system is: air-speed indicator, altimeter, vertical speed indicator, turn- and slip indicator, artificial horizon, trim indication, OAT, HIS incl. CDI and glideslope for ILS approaches. Engine speed, oil pressure, oil temperature, fuel flow, fuel pressure, fuel amount in fuel tank and voltmeter.

| | |
|------|--|
| NOTE | Although the REMOS GXiS equipped with the DYNON SkyView system, which is a very capable and reliable avionic suite, please keep in mind that IFR flights in actual IMC is not permitted as per regulations. |
|------|--|

color code

In aviation it is common to have the HSI pointer displayed green when a VOR or ILS is selected as navigation source. The pointer is magenta when a GPS is selected as navigation source.

joystick

Push, tilt and rotate to select functionality and adjust values, On HDX800/HDX1100, the joystick needs only be rotated and pushed, not tilted.

7 Airplane and Systems Description

| | |
|-------------------|--|
| QNH | Push joystick, tilt up or down to select BARO, then rotate to adjust QNH |
| layout | The screen split and content can be selected by pressing LAYOUT, then the items to be displayed can be selected, e.g. EMS or PFD. SCREEN changes ratio of split screen, BACK gets you back to main menu. |
| HSI operation | Select PFD in main menu and the HIS SRC to select navigation source: SKYVIEW is the internal GPS, external GPS is named explicitly, NAV/COM may be selected as well. BACK gets you back to main menu. |
| adjusting OBS | Select CRS on the joystick, then rotate to select OBS. |
| selecting bearing | Select PFD in main menu and then pick bearing source(s) with BRG 1 and/or BRG 2: SKYVIEW is the internal GPS, external GPS is named explicitly, NAV/COM may be selected as well. BACK gets you back to main menu. The yellow or orange pointer in the HSI shows bearing to the selected VOR or to the next GPS waypoint. |

7 Airplane and Systems Description

7.6 COM and NAV/COM

GARMIN GTR225A

The GARMIN GTR225A is a VHF COM transceiver with 8.33kHz frequency channel spacing. It incorporates a number of functions that save time and effort. Provide the GTR 225 with an airport identifier and it will automatically find its frequency (and vice versa) thanks to a built-in, updateable database. The database technology also allows to store and recall commonly used or recently used frequencies by an assigned name. All information is displayed prominently on the device's large sunlight-readable LCD display.



This POH only provides basic introduction and instructions. For details refer to the manufacturer's instruction manual that comes with your airplane. The website of GARMIN www.garmin.com offers the possibility to download the manuals.

| | |
|----------------|--|
| on/off, volume | The radio is switched on and off by rotating the VOL knob. This knob also adjusts volume. |
| frequency | Frequency is selected with the outer ring and inner selector of the TUNE knob. Frequency selected is displayed in the right of the display. Pressing the flip-flop button ↔ flips standby STB and ACT frequency. |
| monitoring | Pressing MON enables monitoring of the STB frequency at the same time as the ACT frequency. The radio will only transmit on the ACT frequency. The audio quality is reduced. |

7 Airplane and Systems Description

GARMIN GNC255A

The GARMIN GNC255A is a VHF COM transceiver with 8.33kHz frequency channel spacing and a 200-channel VOR/LOC/GS NAV receiver in one combined housing. The GNC255A also incorporates workload-reducing functions such as automatic decoding of the Morse code station identifier for VOR/LOC/ILS, most-used frequency storage in unit memory, built-in course deviation indicator and more.



The GNC255A incorporates a number of functions that save time and effort. Provide the GNC255 with an airport or navaid identifier and it will automatically find all available frequencies (and vice versa) thanks to a built-in, updateable database. The database technology also allows to quickly pull up most frequently or most recently used frequencies. The device even automatically decodes a station's Morse code to provide a positive identification – no aural decoding required.

It offers standby frequency monitoring of NAV and COM providing the capability of two NAV/COMS in one. Standby COM frequency monitoring lets the pilot listen to transmissions like ATIS or the emergency channel without leaving the active frequency.

With the primary VOR/LOC frequency selected as NAV source on the DYNON SkyView, the standby frequency can be tuned to a second VOR to display the current radial on which your aircraft is flying and be displayed as BEARING source on the SkyView. This allows to cross check position fixes with just one receiver, the standby-VOR tuned in serves as an NDB in this case.

on/off, volume

The radio is switched on and off by rotating the VOL knob. This knob also adjusts volume.

7 Airplane and Systems Description

| | |
|------------------|--|
| COM/NAV display | Pressing the C/N button changes display of NAV and COM frequencies. |
| COM frequency | Hit C/N first to select COM frequency band. Frequency is selected with the outer ring and inner selector of the TUNE knob. Frequency selected is displayed in the right of the display. Pressing the flip-flop button ↔ flips standby STB and ACT frequency. |
| NAV frequency | <p>Hit C/N first to select NAV frequency band. Frequency is selected with the outer ring and inner selector of the TUNE knob. Frequency selected is displayed in the right of the display. Pressing the flip-flop button ↔ flips standby STB and ACT frequency.</p> <p>When GNC225A is selected as navigation source on the SkyView, the NAV STB frequency can be tuned into a second VOR and displayed as bearing on the HSI. In this case the VOR serves as NDB.</p> |
| listen to NAV ID | By pressing NAV knob the ID of the VOR station or ATIS on NAV frequency can be monitored. Volume can be adjusted by turning the NAV knob. |
| monitoring | Pressing MON enables monitoring of the STB frequency at the same time as the ACT frequency. The radio will only transmit on the ACT frequency. The audio quality is reduced. |

For detailed data refer to the manufacturer's instruction manual that comes with your plane. The website of GARMIN www.garmin.com offers the possibility to download the manuals.

7 Airplane and Systems Description

PS-Engineering PAR200A

The PS-Engineering PAR200A is a VHF radio with 8.33kHz spacing with integrated intercom. It can manage another radio or NAV/COM (no MKR functionality).



This POH only provides basic introduction and instructions. For detailed data refer to the manufacturer's instruction manual that comes with your plane. The website of PS-Engineering www.ps-engineering.com offers the possibility to download the manuals.

| | |
|----------------|---|
| WARNING | Listening to music during flight may lead to inattention. Take care that you are always aware of the situation of the flight and stay ahead of the aircraft. If in doubt, switch off the audio entertainment, especially during take-off, landing and while talking with ATC. |
|----------------|---|

| | |
|----------------|---|
| WARNING | National regulations may apply or using cell phones on board of aircraft. |
|----------------|---|

7 Airplane and Systems Description

| | |
|-------------------|---|
| on/off, volume | The radio is switched on and off by pushing the VOL knob. This knob also adjusts volume. |
| frequency | Frequency is selected with the outer ring and inner selector of the TUNE knob. Frequency selected is displayed in the right of the display. Pressing the TUNE flips standby and active frequency. |
| monitoring | Pressing N1 for a least 5 seconds enables monitoring of the STB frequency at the same time as the active frequency. The radio will only transmit on the active frequency. The audio quality is reduced. |
| selecting NAV/COM | The PAR200A can manage a second radio or NAV/COM. Selecting a radio from the RCV line allows monitoring to that radio. The intercom will only transmit on radio selected with XMT. |
| VOX squelch | VOX squelch need not be adjusted as the PAR200A is equipped with IntelliVox technology. |
| intercom VOX | Intercom VOX volume is adjusted by turning the outer ring of the VOL knob. |
| BLUETOOTH | Select BLUETOOTH coupling on your phone. The device is named PAR200A, access code is 0000. |

7 Airplane and Systems Description

7.7 Intercom and Audio Panel

PS-Engineering PMA8000BTi

This is an audio panel with marker beacon receiver. It incorporates audio-in capability with several muting modes. The audio panel may be used with mono or stereo headsets.



A common volume knob is provided for left and right seat. Setting squelch is not required as the audio panels incorporate INTELLI-VOX that adjusts squelch automatically.

In addition to that the PMA8000BTi audio panel incorporates BLUE-TOOTH® interface to link your cellphone or iPhone® without additional cables.

| | |
|----------------|---|
| WARNING | Listening to music during flight may lead to inattention. Take care that you are always aware of the situation of the flight and stay ahead of the aircraft. If in doubt, switch off the audio entertainment, especially during take-off, landing and while talking with ATC. |
|----------------|---|

| | |
|----------------|---|
| WARNING | National regulations may apply or using cell phones on board of aircraft. |
|----------------|---|

This POH only provides basic introduction and instructions. For detailed data refer to the manufacturer's instruction manual that comes with your plane. The website of PS-Engineering www.ps-engineering.com offers the possibility to download the manuals.

7 Airplane and Systems Description

| | |
|-------------------|--|
| on/off, volume | The audio panel is switched on and off by pushing the VOL knob. This knob also adjusts volume. |
| selecting NAV/COM | The PMA8000BTi can manage two radios or NAV/COM. Selecting a radio from the RCV line allows monitoring to that radio. The audio panel will only transmit on radio selected with XMT. |
| VOX squelch | VOX squelch need not be adjusted as the PAR200A is equipped with IntelliVox technology. |
| intercom VOX | Intercom VOX volume is adjusted by turning the outer ring of the VOL knob. |
| BLUETOOTH | Select BLUETOOTH coupling on your phone. The device is named PAR200A, access code is 0000. |

7 Airplane and Systems Description


7.8 GPS Equipment

Garmin aera660 und aera 796

The GPS by Garmin are prime class navigation aids with brilliant color screen and touch operation. The GPS is switched on automatically once the ignition key is set to AVIONIC.



aera660




aera 796

7 Airplane and Systems Description


This POH only provides basic introduction and instructions. For details refer to the manufacturer's instruction manual that comes with your airplane. The website of GARMIN www.garmin.com offers the possibility to download the manuals.

Following gestures operate the GPS:

select





zoom




zoom in

scroll



zoom out

pan



Basic operation is done by following icons:


| | |
|-----------|--|
| MAP | shows sectional map |
| NEAREST | shows nearest airfields |
| DIRECT TO | enabled direct navigation to airfield selected |
| FPL List | shows active flightplan and allows programming |
| ZOOM | allows zooming |

7 Airplane and Systems Description

7.9 Transponder

DYNON D600/D700 and D900/D1000

The top bar displays the transponder status as shown below:



To set the transponder hit the softkey XPNDR from the main menu. The XPDR menu will now show up as follows:



| | |
|-------|---|
| GND | turns on ground mode, pressing the softkey again will put the transponder into standby mode |
| ON | activates Mode A, pressing the softkey again will put the transponder into standby mode |
| ALT | activates Mode A/C/S incl. ADS-B out, pressing the softkey again will put the transponder into standby mode |
| CODE | allows to enter a squawk |
| VFR | squawks VFR |
| IDENT | squawks ident |
| BACK | steps back to main menu |

NOTE

With a GPS antenna DYNON SkyView SV-GPS-2020 and the transponder SV-XPNDR-261 installed, the transponder fulfils the FAA ADS-B 2020 mandate.

7 Airplane and Systems Description

DYNON HDX800 and HDX1100

The top bar displays the transponder status as shown below. To set the transponder touch into the top bar in the area that displays the transponder status. The XPDR control page will appear as follows:



| | |
|-----------|---|
| IDENT | squawks ident |
| VFR | squawks VFR |
| BACKSPACE | erases the last input (ued for correcting squawk) |
| 0...7 | enter squawk |
| SBY | puts the transponder into standby mode |
| GND | turns on ground mode |
| ON | activates Mode A |
| ALT | activates Mode A/C/S incl. ADS-B out |
| X | closes the menu |

NOTE

With a GPS antenna DYNON SkyView SV-GPS-2020 and the transponder SV-XPDR-261 installed, the transponder fulfils the FAA ADS-B 2020 mandate.

7 Airplane and Systems Description

7.10 GTN750 GPS/NAV/COM/XPDR/Audio

The GTN750 is an IFR navigator which integrates the functionality of a WAAS GPS with moving map, NAV/COM, transponder and audio panel. This system replaces the transponder integrated into the DY-NON SkyView system.

The systems made by Garmin is a prime class navigation aid with brilliant color screen and touch operation. The system is switched on automatically once the ignition key is set to AVIONIC.



This POH only provides basic introduction and instructions. For details refer to the manufacturer's instruction manual that comes with your airplane. The website of GARMIN www.garmin.com offers the possibility to download the manuals.

7 Airplane and Systems Description

After start-up of the system the home screen appears:



| | |
|-------------|--|
| MAP | activated sectional map |
| TARFFIC | displays surrounding traffic (if installed) |
| FLIGHT PLAN | shows active flightplan and allows programming |
| PROC | activates IFR procedures (if database installed) |
| NEAREST | shows nearest airfields |
| DIRECT TO | enabled direct navigation to airfield selected |
| XPNDR | allows tuning of a COM station |
| NAV | allows tuning of a VOR or ILS station |
| XPDR | sets XPDR mode and squawk |
| HOME | switches back to the home screen |

Volume is set by rotating the upper left knob.

7 Airplane and Systems Description



For details and complete instructions refer to the GARMIN manual.

7 Airplane and Systems Description

7.11 Autopilot

The autopilot of the DYNON system allows holding and changing altitude, and RNAV, i.e. flying along GPS track, GPS waypoint flightplan or along a radial of a VOR (ILS is a special version of a VOR with just one radial).

In the version as offered by REMOS, the autopilot does not offer VNAV, it can only hold or change a selected altitude. The autopilot does not provide vertical guidance on an ILS or GPS-based LPV approaches.

| | |
|-------------|---|
| NOTE | Be responsible when flying with autopilot. The aircraft is not approved for flying in actual IMC. |
|-------------|---|

| | |
|-------------|---|
| NOTE | The autopilot does not look on a map or looks out of the window. The pilot in command is responsible for correct navigation (airspace, obstacles, terrain!!!) |
|-------------|---|

Engaging the autopilot always follows the procedure below:

1. decide for an autopilot mode
2. select navigation source
3. set up navigation source
4. select autopilot mode
5. engage autopilot

7 Airplane and Systems Description

autopilot modes

The DYNON autopilot has two modes:

1. track and altitude (TRK+ALT)

The autopilot keeps your selected altitude, climbs or descends to it and follows a given ground track. Setting up or even select a navigation source is not required.

Track hold keeps the aircraft flying in a particular direction, as determined by GPS's ground track, or direction of travel over ground. This target is reflected by the track (TRK) bug in the HSI. When the autopilot is engaged, the TRK bug will automatically be synchronized to the current ground track of the aircraft. Effectively, this means that the autopilot will keep flying in the same direction that the aircraft was flying in the moment before the autopilot was engaged. After the autopilot is engaged, change the track you want the autopilot to fly by adjusting the TRK bug.

Altitude hold mode keeps the aircraft flying at a particular altitude. The altitude that that autopilot holds is governed by the altitude (ALT) bug. When the autopilot is initially engaged, the ALT bug will automatically be synchronized to the current altitude. Effectively, this means that the autopilot will maintain the altitude that the aircraft was at the moment before the autopilot was engaged. Altitude that the autopilot holds may be adjusted with the ALT bug.

2. HSI and altitude (HSI+ALT)

The autopilot keeps your selected altitude, climbs or descends to it and follows a given ground track. A navigation source must be set up, i.e. either a VOR/ILS needs to be tuned in and a radial need to be selected, or a GPS waypoint flightplan must be set up. In case no navigation source is selected AND set up, this mode cannot be selected.

In HSI mode, the autopilot will fly the lateral course guidance

7 Airplane and Systems Description

that is displayed on the HSI from the provided source. For example, if the selected HIS source is the SkyView GPS, and there is an active flightplan, the autopilot will fly that flightplan. Or if the source is a VOR, the autopilot will seek to capture and hold the set radial to or from the VOR.

Altitude hold mode keeps the aircraft flying at a particular altitude. The altitude that the autopilot holds is governed by the altitude (ALT) bug. When the autopilot is initially engaged, the ALT bug will automatically be synchronized to the current altitude. Effectively, this means that the autopilot will maintain the altitude that the aircraft was at the moment before the autopilot was engaged. Altitude that the autopilot holds may be adjusted with the ALT bug.

navigation sources

A navigation source is the means of lateral (read: left and right steering) navigation for the autopilot. The following navigation sources are available:

1. internal DYNON SkyView GPS
This is always available, no matter what COM, NAV/COM or external GPS is installed. With a waypoint flightplan set up (even direct-to is a flightplan), the autopilot can follow this planned flight.
2. external GPS
In case an external GPS is installed in the center stack, this GPS can be used as navigation source. With a waypoint flightplan set up (even direct-to is a flightplan), the autopilot can follow this planned flight.
3. navigation radio
In case a NAV/COM is installed, this can be used as navigation source. The autopilot can navigate along a radial of a tuned VOR (remember: an ILS is a special version of a VOR with one single radial only).

7 Airplane and Systems Description

control wheel steering

When the autopilot is engaged, press and hold the AP/DISC button on the control stick to put the autopilot into control wheel steering mode.

While control wheel steering mode is active, the autopilot servos are temporarily disengaged. This lets you fly the aircraft by hand for short periods to make an adjustment to the autopilot's targets without completely disengaging the autopilot.

When the disconnect switch is released, the autopilot's targets are adjusted as follows:

TRK+ALT mode

- pitch axis
The ALT bug and therefore the autopilot's altitude target is synchronized with the aircraft's current altitude.
- roll axis
The TRK bug and therefore the autopilot's track target is synchronized with the current GPS track.

HIS+ALT mode

- pitch axis
The ALT bug and therefore the autopilot's altitude target is synchronized with the aircraft's current altitude.
- roll axis
No change, the roll axis resumes tracking its HSI source.

hold to engage

When the autopilot is not already engaged, press and hold the AP/DISC button on the control stick will place the autopilot into hold to engage mode. The top bar annunciates REL TO ENG (release to engage) while the AP/DISC button is held.

Then the AP/DISC button is released, the autopilot engages in TRK+ALT mode. TRK and ALT are synchronized to the aircraft's current GPS ground track and altitude.

7 Airplane and Systems Description

selecting a navigation source (D600/D700 and D900/D1000)

From the main menu select PFD to open the PFD menu, then hit HSI SCR to cycle the HSI through the different navigation data sources that are connected to the SkyView system. Other than SKYVIEW, which is the system's internal GPS, these are all external navigation devices: external GPS or NAVCOM. The name of the selected navigation source is displayed right of the HSI.



main menu



PFD menu

selecting a navigation source (HDX800 and HDX1100)

From the main menu select MENU, then select the PFD TOOLS icon.



main menu (screen content not representative, menu bar only)

7 Airplane and Systems Description



menu page

Now touch HSI SRC to cycle the HSI through the different navigation data sources that are connected to the SkyView system.

Other than SKYVIEW, which is the system's internal GPS, these are all external navigation devices: external GPS or NAVCOM. The name of the selected navigation source is displayed right of the HSI. Select X or EXIT to leave this menu.



PFD menu page

7 Airplane and Systems Description

selecting autopilot mode (D600/D700 and D900/D1000)

Open the autopilot menu from the main menu by pressing the button AUTOPILOT. Now the different modes of the autopilot may be selected.



main menu



autopilot menu

| | |
|---------|---|
| BACK | gets you back into the main menu |
| OFF | disengages autopilot |
| TRK+ALT | Engages autopilot in track and altitude mode. Subsequent presses of this button disengages the autopilot again. To disengage the autopilot you may also hit the AP/DISC button on the control stick. |
| HSI+ALT | Engages autopilot in HSI and altitude mode, this requires to select and set up a navigation source first, otherwise this softkey is greyed out. Subsequent presses of this button disengages the autopilot again. To disengage the autopilot you may also hit the AP/DISC button on the control stick. |
| LEVEL | Press the LEVEL button to engage the autopilot in level mode. For safety in emergency situations, subsequent presses of this button do not disengage the autopilot. To disengage the autopilot, press the OFF button or hit the AP/DISC button on the control stick, or switch to the autopilot modes TRK+ALT or HSI+ALT. |

7 Airplane and Systems Description

180° Pressing the 180° to initiate an autopilot controlled 180 degree turn from the current track while maintaining the current altitude. After the turn the autopilot is in TRK+ALT mode. To disengage the autopilot, hit TRK+ALT, OFF or you may also hit the AP/DISC button on the control stick.

NOTE

The 180° mode will always initiate a LEFT turn.

selecting autopilot mode (HDX800 and HDX1100)

From the main menu select MENU, then select the AUTOPILOT icon. Select X or EXIT to leave any menu.



main menu (screen content not representative, menu bar only)

7 Airplane and Systems Description



menu page

Now the different modes of the autopilot may be selected.



7 Airplane and Systems Description

| | |
|-----------|---|
| EXIT or X | gets you back into the main menu |
| OFF | disengages autopilot |
| TRK+ALT | Engages autopilot in track and altitude mode. Subsequent presses of this button disengages the autopilot again. To disengage the autopilot you may also hit the AP/DISC button on the control stick. |
| HSI+ALT | Engages autopilot in HSI and altitude mode, this requires to select and set up a navigation source first, otherwise this softkey is greyed out. Subsequent presses of this button disengages the autopilot again. To disengage the autopilot you may also hit the AP/DISC button on the control stick. |
| LEVEL | Press the LEVEL button to engage the autopilot in level mode. For safety in emergency situations, subsequent presses of this button do not disengage the autopilot. To disengage the autopilot, press the OFF button or hit the AP/DISC button on the control stick, or switch to the autopilot modes TRK+ALT or HSI+ALT. |
| 180° | Pressing the 180° to initiate an autopilot controlled 180 degree turn from the current track while maintaining the current altitude. After the turn the autopilot is in TRK+ALT mode. To disengage the autopilot, hit TRK+ALT, OFF or you may also hit the AP/DISC button on the control stick. |

NOTE

The 180° mode will always initiate a LEFT turn.

7 Airplane and Systems Description

adjusting altitude

Click on one of the joysticks or kick it up or down and then select the ALT bug by either rotating the joystick or clicking up or down. Once the ALT bug is selected, adjust the bug and therefore altitude by rotating the joystick. On the SkyView HDX800/HDX1100 only a push-and-rotate action is required.

In case these is not sufficient power set for a climb, the autopilot will not pull on the elevator until stall. Furthermore, below a preset speed the autopilot gives up the climb command in favor of airspeed.

In case these is too much power set for a descent, the autopilot will not push on the elevator until airspeed exceeds VNE. Furthermore, beyond a preset speed the autopilot gives up the descent command in favor of airspeed.

adjusting GPS track over ground

Click on one of the joysticks or kick it up or down and then select the TRK bug by either rotating the joystick or clicking up or down. On the SkyView HDX800/HDX1100 only a push-and-rotate action is required. Once the TRK bug is selected, adjust the bug and therefore course over ground by rotating the joystick.

selecting radial (OBS)

Click on one of the joysticks or kick it up or down and then select the CRS by either rotating the joystick or clicking up or down. On the SkyView HDX800/HDX1100 only a push-and-rotate action is required. In case a VOR station is tuned in, the radial can be selected.

| | |
|-------------|---|
| NOTE | An ILS is a special version of a VOR with one radial only, that cannot be selected. |
|-------------|---|

| | |
|-------------|--|
| NOTE | CRS is available only in HSI+ALT mode with a VOR station tuned in. |
|-------------|--|

7 Airplane and Systems Description

7.12 Electric System

general

The REMOS **GXiS** has quite a complex electric system for reliable support of all electric engine and aircraft systems. It is designed for maximum reliability and user-friendliness, as there are a lot of vital electric subsystems installed on the aircraft.

The engine in particular is reliant on electric energy. Following vital engine subsystems are electrically powered: dual channel injection and engine management, ignition, fuel pumps, engine instrumentation.

As the engine imperatively relies on electric power, two generators are installed. One of them (generator A, nominal power output 220W, rated current 16A at 14.2V) is responsible for engine subsystems only, the other one (generator B, nominal power output 420W, rated current 30A at 14.2V) is for the aircraft systems.

After engine start-up, electric power is supplied by generator B, aircraft systems are powered by the batteries. Once engine speed is set above 2,500 rpm for at least 5 seconds, the engine switches to generator A and the aircraft systems are now powered by generator B.

In the unlikely event of a failure of one of the generators, electric power supply for the engine is ensured. In such an event, the engine is powered by the intact generator and the aircraft systems run on batteries only. By activating the “emergency mode” with the emergency switch, the aircraft systems are powered with excess power of the remaining generator and the aircraft batteries.

The aircraft is equipped with two batteries. In case of emergency, both batteries supply energy exclusively; in normal operation, they provide surplus energy for peak power consumption. During engine start-up, one battery supplies power to the engine incl. starter engine and fuel pumps, the other battery is for the aircraft systems and the avionics.

During start-up, the avionic bus is completely separated from the engine bus. By this, the REMOS **GXiS** does not have a dedicated avionic bus switch, bus selection is completely automatic.

7 Airplane and Systems Description

normal operation

To start up the REMOS **GXis** the ignition key needs to be inserted and set into position AVIONIC. Now the following systems are active:

- SkyView system
- ATC radio(s)
- intercom or audio panel
- GPS
- flaps
- trim

Following systems are still inactive:

- engine control
- landing light
- NAV lights
- anti-collision lights

This key position is intended to set-up the avionics, program the GPS, request start-up clearance, etc. Flight schools will prefer this position to introduce the student pilot into the aircraft, the avionics and systems.

Next step is to set the ignition key into position ENGINE. All systems that have been offline until now are switched on. To fire up the engine the central ENGINE START button needs to be hit, the REMOS SMARTstart system takes over control during the start-up process. In cold weather, throttle should be cracked open.

Following procedure is performed in the background during engine start:

- engine start mode is activated
- avionic bus is separated from main bus
- starter engine is engaged
- both electric busses are unified again

7 Airplane and Systems Description

The engine is running now and can be warmed up. For quickest possible warming up it is recommended to keep engine speed below 2,500 rpm. Even at this low engine speed the engine is producing waste-heat, but the cooling system is hardly supplied with fresh air. Higher engine speeds improve cooling and therefore elongate the warm-up phase.

In situations with high traffic on ground, e.g. taxiing for take-off at a fly-in, coolant and oil temperatures can rise significantly. In such a situation either increase engine speed above 3,000 rpm to cool down the engine or timely shut down engine. There is no danger the engine could not fire-up again just because it is hot.

A magneto check in the common sense does not exist in the REMOS **GXis**; the REMOS SMARTstart takes over the check procedure. Once the aircraft is arrested with the parking brake, engine speed is set to 4,000 rpm and the ENGINE TEST button is hit. Following procedure is executed in the background:

- LANE A will be switched off and on again
- LANE B will be switched off and on again
- MAIN fuel pump is shut off
AUX fuel pump kicks in automatically
- fuel system is reset so that MAIN fuel pump is active

The pilot only needs to monitor the engine parameter. A drop in engine speed of not more than 180 rpm is acceptable, though in most cases a slight increase of engine speed up to app. 4,200 rpm will be monitored.

During the test of the engine parameters the MAIN fuel pump will be switched off and the AUX pump will kick in immediately. The EMS page of the SkyView system will generate an aural warning and the "MAIN fuel pump INOP" warning light will come up. The warning will expire after a couple of seconds. The engine will quit during test routine in case the AUX fuel pump is defective. Any malfunction on the fuel system poses a certain risk on safe operation. Therefore, avoid take-off with one fuel pump inoperative.

7 Airplane and Systems Description

In cruise with engine speeds of 4,200 ... 5,800 rpm the fuel pressure will be 43.5 psi +/- 3 psi (3.0 bar +/- 0.2 bar). Lower pressure is acceptable at lower engine speed. During switching of the fuel pumps, the fuel pressure may drop momentarily, but will recover immediately.

Once all tests have been performed satisfactory, the airplane is ready for departure.

| | |
|-------------|--|
| NOTE | All warnings must have expired after the engine test. The orange status light of the TEST button and the red background light of the ENGINE START button must turn off. Should this not be the case, the planned flight must be cancelled. A ferry flight might be possible with special permission, ask REMOS for advice. |
|-------------|--|

The engine lanes LANE A and LANE B are always active as soon as the ignition switch is set to ENGINE. Status of the lanes is shown by the red LANE A/B ALARM lights in the lane switches in the center panel. During normal operation, these warning lights are off. Flashing or permanently lighting status light(s) indicate a lane malfunction, see section 3 – emergency procedures.

Should a malfunction occur on one or both lanes, it should be tried to resolve this problem by resetting the lane in question. To reset a lane, press the corresponding pushbutton LANE A/B RESET (warning light at the same time). The switch comes out now app. 1/8 inch and lights up permanently now. After a couple of seconds the switch is pushed in again, causing the lane to reboot. Rebooting takes about 3 seconds.

Should one lane cause problems permanently, e.g. rough engine running, it may be switched off until landing. The two lane switches are electronically protected against each other in order to prevent inadvertent shut-down of the engine by deactivating both lanes at the same time. Only the one lane whose button has been pressed first will be deactivated. Even with both switches pressed the second lane will only be deactivated when the first lane is switched on.

7 Airplane and Systems Description

emergency operation – single generator failure

The engine needs electric power supply to be able to operate. Without sufficient electric power the engine will quit. Following vital engine sub-systems are electrically powered: dual channel injection and engine management, ignition, fuel pumps, engine instrumentation.

Except of the engine instrumentation, all electric engine systems are vital, read: the engine will quit. By this the electric power supply is designed redundantly. Electric power supply is realized by two generators. Should one of the two generators fail, the remaining generator takes over electric power supply for the engine.

failure of generator A (engine generator)

- engine switches to generator B automatically
- aircraft systems are powered by aircraft batteries only
- indicated by both LANE lights flashing and sloping voltage (into the red marking)

failure of generator B (aircraft systems generator)

- engine stays on generator A
- aircraft systems are powered by aircraft batteries only
- indicated by sloping voltage (into the red marking)

For the pilot the result is identical in both scenarios: the aircraft systems are powered by the aircraft batteries only. To minimize battery discharge, the EMERGENCY MODE shall be activated immediately by flipping the EMERGENCY SWITCH (lift to engage), also to ensure sufficient battery power for the engine systems in case the second generator fails, too.

The EMERGENCY SWITCH is located on the left side of the panel; it is locked for normal operation. To activate the EMERGENCY MODE, lift the switch slightly and put it in its center position. Further tilting to the right would engage the starter engine, which should be avoided while engine is running in order to avoid damages to the starter engine.

Non-essential consumers will be switched off now, these are: position and anticollision lights, 12V receptacle, the SkyView system (has in-

7 Airplane and Systems Description

ternal backup batteries), autopilot and second ATC radio. All other aircraft systems are powered by the aircraft batteries and the excess power of the remaining generator. ATC radio and transponder are also online. By this, the aircraft systems may still be used for an extended time.

The SkyView system has internal backup batteries. Once these are completely discharged, the SkyView system finally fails. Should this be avoided, e.g. when safe landing is ensured, the EMERGENCY MODE can be switched off, so that the remaining battery power can feed all aircraft systems now.

The landing light must be switched off manually in case of a generator failure, but it can still be used for landing.

emergency operation – double generator failure

The engine will definitely quit in case both generator fail. In this case the EMERGENCY SWITCH needs to be activated immediately.

The EMERGENCY SWITCH is located on the left side of the panel; it is locked for normal operation. To activate the EMERGENCY MODE lift the switch slightly and put it in its center position. Further tilting to the right engages the starter engine. The engine should fire up again now.

Non-essential consumers will be switched off now, these are: position and anticollision lights, 12V receptacle, the SkyView system, autopilot and second ATC radio. The SkyView system may be operated on its internal backup batteries, ATC radio and transponder are also online.

The next available airfield shall now be used for landing without any further diverts. The remaining flight time until final engine failure due to lack of electric power is now not more than 30min. After that time the batteries are fully discharged and the engine will definitely and inevitably quit.

| | |
|-------------|--|
| NOTE | After a double generator failure, the remaining safe flight time until engine failure is 30min. After that time the batteries are fully discharged and the engine will definitely and inevitably quit. |
|-------------|--|

7 Airplane and Systems Description

circuit breakers

The fuses installed are of the circuit breaker type, which automatically release after short-circuit or overload. A released circuit breaker stands out approximately 1/4 inch and exhibits a white ring.

The circuit breaker can be reset by pushing it in again.

All circuit breakers can be released manually. To do so, press on the circuit breaker until it releases and stands out.

aircraft batteries

The aircraft batteries on the REMOS **GXis** have a high responsibility regarding safe flight as can be seen from the preceding descriptions. Only batteries with following specification qualify for installation:

| lead battery specification | |
|-----------------------------------|---|
| nominal capacity | min. 9 Ah |
| cold cranking amps | min. 150 A |
| battery type | starter lead gel battery |
| example | Hawker Odyssey PC545 Hawker Genesis 12EP13 |

| lithium battery specification | |
|--------------------------------------|---|
| nominal capacity | min. 8.5 Ah |
| cold cranking amps | min. 150 A |
| battery type | LiFePO4 |
| minimum battery equipment | overload protection overvoltage protection overtemperature protection under voltage protection cell balancing self-contained housing with vent |
| example | EarthX ETX900VNT |

7 Airplane and Systems Description

The recommended battery EarthX ETX900VNT features a battery warning system that is connected to the DYNON SkyView system. Other batteries may also be installed, but in these cases the battery warning feature is not active.

In normal operation, the battery warning light is off (dark cockpit concept); it only comes up in one of the following events:

warning light permanently on

| voltage | possible cause | Recommended action |
|----------------|--|---|
| any | battery management system electronic issue | Not an immediate issue unless it is in conjunction with a charging system failure. In this case: Both the aircraft voltage regulator and aircraft overvoltage protection have failed. Land on appropriate airfield, soon. Consider precautionary landing. |
| any | short circuit protection was activated | Solid light will turn off without further action, noting needs to be done. |

warning light flashing

| voltage | possible cause | action |
|-------------------|-------------------------|---|
| < 13.2 V | battery over-discharged | Charge battery on ground. Once charged, the light will stop flashing. |
| < 13.2 V | weak or failing cell | Charge battery on ground. If voltage drops below 13.2V within a few days, discontinue use. |
| 13.2 V ... 14.6 V | weak or failing cell | Discontinue use. If in flight, this is not an immediate issue unless it is in conjunction with a charging system failure. |

7 Airplane and Systems Description

| | | |
|-------------------|---|---|
| 13.2 V ... 14.6 V | cell to cell charge levels are not balanced | May come on briefly during periods of high current charging until the cells are automatically balanced. Try charging with a plugin charger. |
| > 15.2 V | over-charging | Both the aircraft voltage regulator and aircraft over-voltage protection have failed. Land on appropriate airfield, soon. Consider precautionary landing. |

| | |
|-------------|--|
| NOTE | When the SkyView display is not set to 100% engine page, the battery warning light is not visible. In this case, battery warning is limited to the master warning light (bottom right in the DYNON system) and a general audio warning ("engine monitor"). |
|-------------|--|

7 Airplane and Systems Description

overvoltage protection

The aircraft is equipped with an overvoltage protection. This subsystem protects the aircraft systems and the avionics in case of an overvoltage event.

The overvoltage protection is integrated into the PSU (power supply unit) and needs neither maintenance nor operation. In case the overvoltage protection releases due to a voltage regulator failure, it isolates the electric system from the engine charging system.

In such an event, the overvoltage warning light in the DYNON system lights up, followed by a low voltage warning. For the pilot, this has the identical effect as a generator failure: charging power of the generators is not available anymore and the aircraft batteries will discharge.

As soon as the electric system is shut down, the overvoltage protection automatically resets. No additional action items are required.

A thorough maintenance event is required to determine the reason for the overvoltage event. The most likely reason is found in a regulator failure of generator B.

7 Airplane and Systems Description

7.13 Engine

general

The ROTAX 912 iS Sport is a horizontally opposed 4-cylinder 4-stroke spark ignition engine with electronically controlled fuel injection. The engine features one central camshaft, driving two overhead valves per cylinder by push rods and hydraulic tappets.

Displacement is 1,352 cm with a compression ratio of 10.8:1.

Max. rated power for 5 minutes is 73.8 kW (100 HP) at 5,800 rpm, max. cont. power is 75 kW (95 HP) at 5,500 rpm

The engine is rotating clockwise, seen from the back.

engine control

The engine features a fully redundant digital engine management and control system (EMS), it includes fuel injection and characteristic ignition.

fuel system

The engine is designed to be operated with no-lead fuel min. AKI 91 (min. MOZ87, min. ROZ 95). Only fuel acc. to ROTAX Service Instruction SI-912i-001 in its latest revision may be used. Best are fuels without water and/or ethanol. AVGAS may be used, but prevailing use reduces the oil change interval.

Fuel is fed to the engine by an electric fuel pump unit located underneath the fuel tank. Nominal fuel pressure is 43.5 psi (3 bar). The fuel pump unit consists of two separate fuel pumps, one alone is sufficient for safe engine operation. In normal operation, fuel is fed to the engine by the main fuel pump. The auxiliary fuel pump serves as backup pump. In case the main pump fails or does not deliver sufficient fuel pressure, the aux pump will be automatically activated and the main pump is switched off.

7 Airplane and Systems Description

| | |
|-------------|--|
| NOTE | Both fuel pumps will deliver identical fuel flow. Technical wise engine operation on aux fuel pump is possible without any restrictions. However, in this case there is no redundancy anymore for a vital engine system. The next suitable airfield should be used for landing and a flight should never be started with one INOP fuel pump. |
|-------------|--|

The fuel system features a self-actuating fuel shut-off valve. As soon as the fuel pumps to not deliver any fuel flow, the fuel line is shut-off automatically. As there are only the electric fuel pumps that deliver fuel to the engine, the engine is shut-down reliable with the ignition key that as well shuts off the fuel pumps.

Two fuel filters are installed in the fuel system: one coarse filter installed inside the fuel tank, and a fine filter with 8...12 microns in the engine compartment that filters fuel just before it is fed into the engine.


A pressure switch for the automatic fuel pump selection is installed behind the self-actuating fuel shut-off valve. The pressure sensor for sensing fuel pressure to be indicated in the DYNON SkyView is installed at the fuel fine filter.

Fuel on board is sensed by a floating sensor inside the fuel tank and is indicated in the DYNON SkyView. This indication is comparable exact. However, different flight attitude changes fuel level sensing and therefore indication, especially with little fuel on board. The fuel tank is equipped with a sight hose behind the right seat to detect fuel level.

The sight hose at the fuel tank behind the right seat is the relevant fuel indication on the REMOS **GXiS**.

There is a draining valve installed at on the fuel tank accessible from the outside belly of the fuselage behind the main landing gear. This valve is used for draining and dumping fuel. Only a white plastic tube is visible of that valve. Press on that hose to drain, press and rotate to lock the valve for dumping fuel. The fuel system vent line is routed to the fuselage belly as well.

7 Airplane and Systems Description



7 Airplane and Systems Description

combustion air

The engine is aspirated with combustion air by a NACA inlet on the right lower side of the cowling. Using a flexible hose, air is routed to the air filter.

The APTS sensor for sensing intake air temperature and static pressure is installed into the NACA inlet.

An intake silencer is installed into the air hose. It reduces intake noise and separated coarse particles like snow, rain or ice from the airstream.

The air filter is installed on the manifold adaptor. This adaptor is installed to the engine throttle body and allows attachment of the air hose named before.

Between air filter and throttle body an automatic alternate air valve is installed onto the manifold adaptor- This is an integral element, which two elastic flaps open automatically at a certain suction pressure. This suction pressure is only reached when the air filter is blocked, e.g. when flying in icing rain. In this case the engine is aspirated with clean, but unfiltered air from inside the cowling. The intake cross section is reduced; therefore engine power is reduced by approximately 25%. Nevertheless, safe flight to a suitable airfield is ensured.

cooling

The engine features cylinder cooling by RAM air, liquid cooled cylinder heads and an oil cooler.

Cylinders are cooled with RAM air, which is guided from the right side of the bisected intake underneath the spinner to a cooling hood on the cylinders.

Oil and water coolers are installed underneath the engine and are provided with air by one common air scoop. Two cooling systems are available:

7 Airplane and Systems Description

- LSA cooling system
recommended for standard operation even in higher ambient temperatures of up to app. 100°F (40°C)
- tropic cooling system
for operation under tropic conditions

The cooling system is designed for clean oncoming airflow. This is hardly given during ground operations. Therefore, the engine is heating up quickly and is ready for departure really soon. For warming up the engine it is recommended to keep engine speed below 2,500 rpm. Higher engine speeds improve cooling and therefore elongate the warm-up phase.

In situations with high traffic on ground, e.g. taxiing for take-off at a fly-in, coolant and oil temperatures can rise significantly. In such a situation either increase engine speed above 3,000 rpm to cool down the engine or timely shut down engine. There is no danger the engine could not fire-up again just because it is hot.

The water cooling system includes a thermostat that regulates water temperature to app. 190...210°F (90...100°C).

The cooling system is serviced with a mixture of conventional coolant and water. Under all normal operation conditions this cooling system and coolant should be sufficient. Upon delivery the aircraft is serviced with BASF Glysantin G48, mixing ratio is 1 part G48 and 1.5 parts water.

Should cooling temperature be in the critical range, the amount of water may be increased. This reduced coolant temperatures. Pure water shall never be used as the coolant is not only protection against freezing, but also against corrosion and delays boiling.

The content of Glysanting G48 shall never be less than 33% and never more than 60%. Following mixing ratios shall be kept:

7 Airplane and Systems Description

| frost-proof up to | for ambient temperatures up to | share Glysantin G48 | share water |
|----------------------|-----------------------------------|------------------------|----------------|
| -4°F (-20°C) | +100°F (+40°C) | 1 | 2 |
| -17°F (-27°C) | +95°F (+35°C) | 1 | 1,5 |
| -36°F (-38°C) | +86°F (+30°C) | 1 | 1 |

cabin heating system

The cabin heating system of the REMOS **GXis** is powered by the water cooling system. A certain share of the coolant is fed to the cabin heat exchanger by a separate water pump. The current of water varies with heating demand and is controlled with the temperature knob in the cockpit. Cabin heating air is fed from the left side of the bisected in let underneath the spinner to the cabin heat exchanger and from there into the cabin.

Conventional aircraft heating systems guide fresh air to a shroud around the silencer and from there into the cabin. The cabin heating system of the REMOS **GXis** is based on hot coolant, hence carbon monoxide cannot enter the cabin through the cabin heating system.

7 Airplane and Systems Description

7.14 Propeller

The aircraft is equipped with the DUC Hélices FLASH propeller. This is a three-blade carbon fiber, ground adjustable propeller, equipped with a plastic spinner.



| | |
|-------------|--|
| NOTE | Although the propeller is technically spoken a ground adjustable propeller, the owner/operator may not change prop pitch. The correct pitch is defined in the aircraft TCDS and in the maintenance manual. |
|-------------|--|

7 Airplane and Systems Description

7.15 Throttle and Brakes

Throttle and brakes are operated by one single lever in the center console. The parking brake valve is located adjacent the combined throttle/brake lever on the center console. The combined functionality of the throttle/brakes lever is as follows:

- Power is advanced by pushing the power/brake-lever forward from idle position.
- Pulling the lever backwards beyond the idle stop activated braking whilst the engine keeps idling. Brake pressure is built up and fed simultaneously through the brake lines to the left and right brake cylinders.

Applying brakes while the engine is not in idle position is not possible on the REMOS **GXis**. This increases comfort and minimizes wear on the brakes.

A parking brake valve is installed on the center console just behind the power/brake lever. Close this valve and apply some, but no excessive brake pressure (this is also the proposed procedure for engine test). Should it reveal that not enough brake pressure has been applied, apply brakes again with the parking brake kept closed.

| | |
|-------------|---|
| NOTE | Change brake pads early enough, otherwise the brake cylinder may slide out of its housing and the brake is damaged. |
|-------------|---|

7.16 Flaps

Flaps on the REMOS **GXis** can be set in three positions: up, 15° for take-off and approach and 35° maximum deflection for landing.

Flaps are set with the flap-shaped switch in the center of the instrument panel. The flap setting can be verified with a look outside on the flaps.

Maximum speed is limited depending on flap setting, see section 2.

7 Airplane and Systems Description

7.17 Heating and Ventilation

The upper corners of the windscreen feature fresh air nozzles. These can be adjusted in outlet direction. Airstream is adjusted by rotating the front ring.

Small vents are installed in the door windows. Pulling back the small handle allows opening the vents in two steps.

The center panel features heating and fresh air control. The left knob allows adjusting the airstream whether the right adjusts temperature.

7.18 Seats

The seats can be installed in three different positions. The more forward the seat is installed, the higher is the seating position.

To take out the seat, press in the release knob underneath the seat close to the door about 1...2 inches. Now the seat can be lifted on its outboard side and pulled out to the door.

Installation of the seat is done in reverse order. Slide in the two arresting pins of the seat into the desired position in the center console, push the release knob and push the seat down into its rail at the door. The seat taches once the release knob is released.

| | |
|-------------|--|
| NOTE | Always check that the seats are safely locked. |
|-------------|--|

7 Airplane and Systems Description

7.19 Baggage and Luggage

Place light luggage below the luggage nets behind the seats. The max. weight for luggage is 4.4 lbs per side. Make sure the recovery system is not blocked.

Larger baggage must be stowed in the baggage compartment behind the pilot seat. It is accessible with the pilot seat taken out. Baggage is limited to 66lb in this compartment.

Even if volume permits, the max. baggage is defined by weight!

7.20 Cockpit Lighting

The REMOS **GXis** cockpit features an effective LED panel lighting system, which can be dimmed independently from the instrument lights. It is a dazzle-free system designed for Night-VFR use.

The system is activated and dimmed by means of the control knob located on the center stack left of the flap switch.

7.21 External Lights

The external lighting system consists of nav-lights, anti-collision lights (strokes) and a landing light. All lights are using LED technology, conventional light bulbs are not used on the REMOS **GXis**.

Nav- and anti-collision lights switch on automatically as long as the ignition key is set into ENGINE position. In case these lights shall intentionally switched off, the circuit breakers need to be released.

The landing light is switched on and off with the toggle switch in the center of the instrument panel, adjacent to the flap selector switch.


7 Airplane and Systems Description

7.22 Recovery System

The recovery system must be installed according to the approved procedures. The belts of the system are attached to the wing's main spar attachment fittings. They are protected against environmental conditions and are maintenance free. A check is neither required nor possible, as the belts are hidden within the airplane's structure.

The main belt is hanging inside the cabin. In case of an installed recovery system the parachute is connected to this belt by means of a snap hook.

| | |
|--------------|--|
| NOTES | <p>Any modification of the installation of the recovery system and any of its components is not authorized and will immediately lead into loss of certification of the airplane.</p> <p>Maintenance during the annual condition inspection must be performed according to the recovery system manufacturer's handbook.</p> |
|--------------|--|



7 Airplane and Systems Description

7.23 Special Equipment and Customizing

The aircraft may be equipped with special or additional equipment on customer's demand. The installation of this equipment must be approved by REMOS and listed in the equipment list.

Avionics other than those mentioned in this manual may be installed on customer's demand. These avionics systems may replace the equipment mentioned in this manual in part or whole. The installation of this equipment must be approved by REMOS and listed in the equipment list.

For operating instructions please refer to the manuals belonging to the equipment installed.

| | |
|-------------|---|
| NOTE | The owner of the aircraft is responsible to keep the aircraft airworthy and comply with all applicable regulations. |
|-------------|---|

7 Airplane and Systems Description

intentionally left blank

8 Aircraft Ground Handling and Servicing

Table of Content

| sect. | description | page |
|--------------|--|-------------|
| 8.1 | Introduction | 8-2 |
| 8.2 | Checking and Servicing Coolant | 8-2 |
| 8.3 | Checking and Servicing Oil | 8-2 |
| 8.4 | Servicing with Fuel | 8-4 |
| 8.5 | Approved Coolant Grade and Specification | 8-6 |
| 8.6 | Approved Oil Grade and Specification | 8-7 |
| 8.7 | Approved Fuel Grade and Specification | 8-8 |
| 8.8 | Towing | 8-10 |
| 8.9 | Tie-Down | 8-10 |
| 8.10 | Rigging a Folded Aircraft | 8-11 |
| 8.11 | Folding a Rigged Aircraft | 8-13 |
| 8.12 | Transportation of the Aircraft | 8-14 |
| 8.13 | Cleaning and Care | 8-14 |

8 Aircraft Ground Handling and Servicing

8.1 Introduction

This section gives guidance how to service the aircraft and how to handle it on ground. This section does not provide maintenance instructions.

Maintenance procedures are defined in the maintenance manual that is specific to the individual aircraft. All maintenance shall be performed according to the REMOS Service and Maintenance Checklist, available directly at REMOS or on the website www.remos.com

8.2 Checking and Servicing Coolant

The REMOS **GXis** is designed to be easily serviceable. A flap in the upper cowlings allows checking the coolant level in the overflow bottle without removing the cowlings. Make sure there is app. 3 inch of coolant liquid visible in the overflow bottle.

In case coolant must be added, remove upper cowlings and add coolant into the overflow bottle. This can be done with a cold or hot engine.

Approved coolant grade and specification can be obtained from section 8.5 of this manual.

8.3 Checking and Servicing Oil

The REMOS **GXis** is designed to be easily serviceable. Access to all components which have to be lubricated or checked regularly is possible without detaching any panels. A flap in the upper cowlings allows access to the oil bottle in order to check and add oil without removing the cowlings.

For checking the oil remove the oil tank cap. Prior to oil check turn the propeller by hand in the direction of engine rotation several times to pump oil from the engine into the oil tank. It is essential to build up compression in the combustion chamber. Maintain the pressure for a few seconds to allow the pressure flow around the piston rings into the

8 Aircraft Ground Handling and Servicing

crankcase. The speed of rotation is not important for the pressure transfer into the crankcase. This process is finished when air is returning back to the oil tank and can be noticed by a murmur from the open oil tank.

The oil level should be between the minimum and maximum marking on the oil dipstick. Avoid oil levels exceeding the maximum mark as excess oil will be poured through the venting line.

Difference between “min” and “max” marking is app. 0.5 quarts.

Approved oil grade and specification can be obtained from section 8.6 of this manual.

8.4 Servicing with Fuel

fueling the aircraft

The fuel system is grounded to the aircraft engine and its subsystems. Before fueling have the aircraft grounded on the exhaust pipe underneath the front belly.

The filler cap is not locked. To open the filler cap (on fuselage shoulder behind right wing root) open lid and rotate about 1/8 turn, then pull filler neck out of fuel tank inlet. The filler cap is not connected with the aircraft, stow it separately while fueling the aircraft. The filler neck is sufficient in size to accommodate an AVGAS gas pump nozzle and the venting of the fuel tank allows quick filling.

When fueling the airplane, fuel will spill out of the venting line on the belly of the fuselage once the fuel tank is full. To avoid or minimize environmental pollution, put a vat underneath the venting line. Alternatively, fill up fuel until the sight gauge indicates full and do not add more than two US gallons beyond this point.

8 Aircraft Ground Handling and Servicing

shifting of CG

The fuel tank is located behind the CG, which in return travels aft when filling the tank. Due to the CG shift during fueling it is possible that the aircraft settles on its tail. This might happen especially with the baggage compartment loaded up to its limit and without an occupant. This does not indicate a CG out of range. Nevertheless, always have your weight and balance checked before take-off.

drainining

Since auto fuel contains a significant amount of ethanol nowadays, draining of the fuel system is more and more important. Draining of the aircraft must be performed before moving the aircraft at all. After re-fueling the aircraft, draining is also required. Give the fuel several minutes to rest after filling it up and do not move the aircraft prior to draining.

The drainer is located underneath the belly, just behind the main landing gear. From the outside, only a plastic hose with 0.5 in diameter is visible. To drain the fuel tank, press on the plastic hose. Capture the released fuel and analyze it for water.

If AVGAS or MOGAS is used, water will clearly deposit underneath the fuel. Continue draining until no more water can be detected.

In the case of auto fuel containing ethanol, water can be absorbed by the fuel up to a certain amount, so no water will be detected during draining. If the fuel looks like a milky dispersion, the fuel is saturated with water. In this case, dump all of the fuel, do not use this fuel for flying! After dumping fuel, fill up the fuel tank completely with fuel without ethanol.

To dump fuel, press in the plastic drainer hose and turn it counter-clockwise (as seen from bottom) about $\frac{1}{4}$ of a turn. To close the drainer, turn the plastic hose back. Be sure the drainer is properly closed. If dust or dirt particles get inside the drainer, the drainer will not close properly. In this case, open the drainer again to clean the drainer.

8 Aircraft Ground Handling and Servicing

When draining, the aircraft take care that no fuel contaminates the environment. Dispose of drained or dumped fuel in an environmental correct manner.

further information

For further information about fuel containing ethanol please refer to the REMOS Notification NOT-001-ethanol-fuel and the ROTAX Service Instruction SI-912i-001.

8 Aircraft Ground Handling and Servicing

8.5 Approved Coolant Grade and Specification

Coolant liquid consists of a mixture of water and Glysantin Protect Plus/G48. There are several coolant fluids on the market and some of them have been released by ROTAX as being suitable. However, REMOS has tested and therefore released only one specific coolant:

| | | | |
|-------------------------|-------------|---|-----------|
| specification | | conventional coolant with silicate-based corrosion inhibitor mixed with plain water | |
| coolant quantity | min. | 2.4 qts | (2.3 ltr) |
| | max. | 2.9 qts | (2.7 ltr) |
| approved coolant | | BASF Glysantin Protect Plus/G48 | |

Keep following mixing ratios (for further information see section 7):

| frost-proof up to | for ambient temperatures up to | share Glysantin G48 | share water |
|------------------------------|---|--------------------------------|------------------------|
| -4°F (-20°C) | +100°F (+40°C) | 1 | 2 |
| -17°F (-27°C) | +95°F (+35°C) | 1 | 1,5 |
| -36°F (-38°C) | +86°F (+30°C) | 1 | 1 |

| | |
|-------------|---|
| NOTE | The use of waterless coolant is not approved! |
|-------------|---|

| | |
|-------------|--|
| NOTE | <p>Please refer to REMOS notification NOT-001 and ROTAX SI-912i-001 latest revision for further information on suitable engine fluids (fuel, oil, cooling liquid, additives, etc).</p> <p>Have a frequent look on www.flyrotax.com and on www.remos.com for the latest information.</p> |
|-------------|--|

8 Aircraft Ground Handling and Servicing

8.6 Approved Oil Grade and Specification

Due to high stresses in the reduction gears, oils with gear additives such as AeroShell Oil Sport Plus 4 are highly recommended. Because of the incorporated friction clutch, oils with friction modifier additives are unsuitable because this could result in clutch slipping during standard operation.

Avoid oils strictly specified for use in Diesel engines. These may not be suitable due to insufficient high temperature properties and additives that may affect the operation of the slipper clutch in the gear box.

There are several oils on the market and some of them have been released by ROTAX as being suitable. However, REMOS has tested and therefore released only one specific oil:

| | | | |
|----------------------|-------------|------------------------|-----------|
| specification | | RON 424 | |
| viscosity | | 10W-40 | |
| oil quantity | min. | 3.2 qts | (3,0 ltr) |
| | max. | 3.7 qts | (3.5 ltr) |
| approved oil | | AeroShell Sport PLUS 4 | |

| | |
|-------------|---|
| NOTE | Please refer to REMOS notification NOT-001 and ROTAX SI-912i-001 latest revision for further information on suitable engine fluids (fuel, oil, cooling liquid, additives, etc). |
| | Have a frequent look on www.flyrotax.com and on www.remos.com for the latest information. |

8 Aircraft Ground Handling and Servicing

8.7 Approved Fuel Grade and Specification

The use of automotive fuel, including such with up to 10% ethanol, is approved for the REMOS **GXiS**. Premium automotive fuel without ethanol is recommended, though. Such fuel is often referred as MOGAS.

The use of AVGAS, with or without lead, is approved on the REMOS **GXiS**, though fuel without lead shall be preferred as prevailing use of 100LL reduces oil change interval from 100h to 50h.

Fuel additives under the names of Decalin® and Alcor TCP®, which aid the scavenging of lead deposits, have not been tested by ROTAX or REMOS. Field experience shows that these products have no detrimental effect on the engine, when used in the recommended manner. Always follow the additive’s manufacturer instructions especially with regard to health and safety precautions. ROTAX only has field experience with Decalin Runup® and Alcor TCP® brands. Other similar additives are not recommended as ROTAX cannot comment on their suitability.

| | | |
|----------------|--------|--|
| fuel quantity | usable | 22 US gal (84 litres) |
| | total | 21 US gal (80 liters) |
| fuel qualities | | Fuel released by actual revision of ROTAX service instruction SI-912i-001, preferably free of ethanol. |

| | |
|------|---|
| NOTE | Please refer to REMOS notification NOT-001 and ROTAX SI-912i-001 latest revision for further information on suitable engine fluids (fuel, oil, cooling liquid, additives, etc). |
| | Have a frequent look on www.flyrotax.com and on www.remos.com for the latest information. |

8 Aircraft Ground Handling and Servicing

At the time of releasing this POH, following fuels have been found suitable by ROTAX and have been approved by REMOS. This list may be revised by a REMOS NOTIFICATION.

| | | |
|---------------------------|-------------------------------|--|
| minimum fuel grade | | RON 95 (research octane number) MON 87 (motor octane number) AKI 91 (anti knock index) |
| MOGAS | European standard | EN 228 Super EN 228 Super plus |
| | Canadian standard | none released |
| | Russian standard | none released |
| | South African standard | SANS 1598:2006 Clean Fuels (CF2) |
| | US standard | none released |
| | Ukrainian standard | DSTU 4839-2007 A-95 Euro A-98 Euro |
| | Indian standard | IS 2796:2008 MG95 |
| | unleaded brand (*) | GAZPROM B-92 GAZPROM B-92/115 |
| AVGAS | leaded | ASTM D910 (AVGAS 100LL) |
| | unleaded | none released |
| | unleaded brand (*) | TOTAL AVGAS UL91 |

- (*) Fuels were verified as good by ROTAX at the time of release of this handbook. REMOS and ROTAX reject any liability if the fuel manufacturer changes the composition of the fuel.

8 Aircraft Ground Handling and Servicing

8.8 Towing

Due to the low weight of the REMOS **GXis**, it is very easy to move the aircraft by hand on the ground. That's why there is no special equipment for towing provided. Do not attempt under any circumstances to tow the aircraft by attaching any kind of towing equipment to the nose wheel!

Grab the aircraft at the propeller roots just outside the spinner to pull it forward. For pushing the aircraft backward, it is recommended to push at the root of the horizontal tail. Pushing backward is also permitted at the strut. If this is done with open doors, one can grab the rudder pedal to steer backward.

8.9 Tie-Down

To tie down the aircraft it is recommended to use of at least three ropes (left wing, right wing, and tail).

The aircraft is equipped with a metric M8 thread on the lower side of the wing near the wingtips, bolt-in lugs and are provided. If required, bolt in the lugs and tie down the aircraft there. Do not fly with the tie-down lugs installed! The aircraft can also be tied down on the upper strut attachments.

Another rope connection point is provided on the tail skid of the aircraft.

Secure the control stick by use of the safety belt to prevent the control surfaces from being slammed from stop to stop by the wind.

NOTE

The maximum wind velocity to leave a tied down aircraft in the open is 38 kts.

8 Aircraft Ground Handling and Servicing

8.10 Rigging a Folded Aircraft

The REMOS **GXis** is manufactured to the highest quality standards. All components are very precise and provide the maximum aerodynamic quality. It is therefore strongly recommended that you be very careful when assembling or disassembling components such as the wings, stabilizer and other parts. The following instructions will provide you with all the necessary information.

| | |
|-------------|---|
| NOTE | Folding or unfolding the wings and attaching or detaching the horizontal tail is a two-person procedure. Do not try this alone. Severe damage to the aircraft may result. |
|-------------|---|

tools, equipment and preparation

- bolt release tool (provided with the aircraft)
- screwdriver (Philips head)
- grease for bolts

ringing folded wings

1. Withdraw the main wing bolt from the wing and place it nearby. Ensure that the bolt stays clean until remounted.
2. Remove the wing support aid bracket while a second person supports the wing at the wing tip.
3. Now the second person at the wing tip moves the wing slowly forward while ensuring that the wing does not spin around its axis. The weight of the wing is supported by its strut, therefore, the wing must never be lifted or pushed down from the top.
4. When the wing has reached its maximum forward position, the person at the fuselage position must rotate the wing to align both connection latches. Care must be taken that the surface of the wing is not damaged by the fuselage connecting latches.
5. When the connecting latches between the fuselage and wing are aligned, the wing must be lifted by the person at the wing tip. The person at the fuselage must ensure that the flap drive connection fits correctly into the bushing on the fuselage.

8 Aircraft Ground Handling and Servicing

6. If all latches have engaged and the wing fits properly to the fuselage, the main bolt can be pushed into its support tube. To install the main bolt correctly, please use the special installation tool which comes with the aircraft. Now secure the bolt with the securing pin. The person at the wing tip can now release the pressure supporting the wing tip.

7. Inside the cabin, the pushrod quick fasteners **MUST** properly be connected and secured.

8. **Insecure connection, improper operation of control surfaces or insecurely locked fasteners will lead to loss of control of the aircraft!! When in doubt contact your local REMOS dealer or service center.**

Repeat steps 1 thru 8 with second wing.

8 Aircraft Ground Handling and Servicing

installing the horizontal tail

1. Hold the horizontal tail in place so that the bushings in the fuselage match up with those in the horizontal tail.
2. Apply the attachment bolts from left to right into their bushings. The forward bolt is marked by a "V", the rearward bolt by "H".
3. Align the hole of the attachment bolt with the one in the right bushing and secure the bolts with Fokker needles.
4. Connect the cable plug for the electric trim actuator

5. The pushrod quick fasteners **MUST** be connected properly and secured.

Insecure connection, improper operation of control surfaces or insecurely locked fasteners will lead to loss of control of the aircraft!! When in doubt contact your local REMOS dealer or service center.

6. Attach the tail cover and secure it with the screws provided. Connect the electric jack for the taillight.

After rigging the aircraft perform a preflight check.

8.11 Folding a Rigged Aircraft

To disassemble the aircraft, perform the above described procedures in reverse order.

8 Aircraft Ground Handling and Servicing

8.12 Transportation of the Aircraft

If you intend to store the aircraft with the wings folded, we recommend using REMOS folding wing supports (ask your local dealer). With these supports mounted, the wings are secured properly and handling of the aircraft will be much easier.

When the aircraft has to be moved by trailer, please ask your authorized REMOS dealer for advice. When placed on a trailer in a wrong way, serious damage could result.

In any case, make sure the aircraft is properly fixed and cannot move under any circumstances. The wingtips must be supported, so that the weight of the wing is on the support and not on the strut.

8.13 Cleaning and Care

After every day of flight, it is recommended that you clean the surface of the aircraft using pure water and a soft cotton towel only. Take special care when cleaning the windows to use lots of water to loosen and rinse away bugs and dirt and use with only a soft cotton towel, or otherwise you will create scratches. If cleaned regularly, you may not need to use any special cleaning products. If for any reason special cleaning products need to be used, please contact your dealer for advice. For polishing you can use almost any car polish but be sure that no silicone is used in that product.

8 Aircraft Ground Handling and Servicing

intentionally left blank

Imprint

Pilot Operating Handbook REMOS **GXiS**

ASTM Edition

Copyright REMOS AG
© REMOS 2017, all rights reserved

REMOS



REMOS GXiS

POH Supplement – Flight Training

Supplement Flight Training

Table of Content

| sect. | description | page |
|-------|--------------|------|
| 1 | Introduction | 9-2 |
| 2 | Take-Off | 9-3 |
| 3 | Climb | 9-4 |
| 4 | Cruise | 9-5 |
| 5 | Stall | 9-6 |
| 6 | Slip | 9-7 |
| 7 | Glide | 9-8 |
| 8 | Descent | 9-9 |
| 9 | Approach | 9-10 |
| 10 | Touch Down | 9-12 |

1 Introduction

This chapter should enable you to familiarize yourself with the flight performance and flight characteristics of the REMOS **GXis**. To complete these instructions, please refer to the appropriate sections in the POH.

The following pages describe flight characteristics experienced during various flight configurations and weather conditions:

- Take-off
- Climb
- Cruise
- Stall
- Slip
- Glide
- Descent
- Approach
- Touch down

| | |
|-------------|---|
| NOTE | This chapter was introduced as an additional guide to experience the capabilities of the aircraft, It is not a substitute for flight school training! If you are not yet familiar with the aircraft, we strongly recommend that you follow these instructions only when accompanied by a skilled flight instructor. |
|-------------|---|

2 Take-Off

Take-off under normal conditions (comfort take-off)

1. After the pre-flight check has been completed, taxi into position. Standard take-off is with flaps up, on grass select flaps 15°.
2. Elevator trim in take-off position, i.e. 2/3 up.
3. Whenever possible, take-off directly into the wind. The maximum demonstrated crosswind component is 15 kts.
4. Smoothly apply full throttle (fully forward) and maintain runway heading.
5. As the aircraft accelerates, gently pull back on the control stick to raise the nose slightly until the aircraft becomes airborne at about $V_{LO} = 45...55$ KIAS.
6. Once airborne, slowly release the back pressure on the control stick to allow the airspeed to increase to $V_Y = 60$ KIAS. Maintain this speed and avoid making any climbing turns until a sufficiently safe altitude has been reached.
7. When at safe altitude, retract the flaps (if they were deployed).

Take-off under tailwind conditions

Similar to normal take-off except that the take-off distance will be extended. Ensure that you determine the take-off distance required to ensure you have sufficient runway length prior to take-off.

Take-Off in rain or with a dirty aircraft

Surface conditions, high density altitude and temperatures, raindrops and bugs affect the performance of the aircraft. Be aware that in these conditions the performance figures will not meet the published figures, as they apply to a clean aircraft under standard atmospheric conditions. Expect a significant drop in performance.

3 **Climb**

Climb with Best Angle of Climb

With engine set to full power, establish $V_X = 50$ kIAS for any flap setting. At this airspeed, the aircraft will achieve the steepest angle of climb. During climb it is essential to monitor oil and water (CHT) temperatures.

Climb with Best Rate of Climb

With engine set to full power, establish $V_Y = 60$ kIAS with flaps up. At this airspeed, the aircraft will achieve the best rate of climb. During climb it is essential to monitor oil and water (CHT) temperatures.

Climb while in cruise

If you wish to climb in cruise, select an airspeed between 70 to 80 kIAS. At these speeds, the aircraft will climb between slower than best rate of climb due to the higher airspeed.

| | |
|-------------|--|
| NOTE | It is strongly recommended that you monitor oil and water (CHT) temperatures. Under no circumstances should any of the engine temperature limits be exceeded, otherwise, an engine failure may result. |
|-------------|--|

Climb in rain or with a dirty aircraft

Raindrops and bugs affect the performance of the aircraft. Be aware that in these conditions the performance figures will not meet the published figures, as they apply for a clean aircraft under standard atmospheric conditions. Expect a performance loss of 10% to 15%.

4 Cruise

Normal cruise

An economical cruise is flown at engine speeds of 4,400 RPM to 4,800 RPM. High speed cruise is done with engine speeds between 5,000 RPM and 5,400 RPM.

If required, the aircraft is capable of achieving an airspeed up to 119kTAS at full power settings. If doing so, always monitor the engine speed. The maximum continuous engine speed is 5,500 RPM and may only be sustained for 5 minutes. Do not exceed the maximum engine speed of 5,800 RPM.

Cruise in gusty conditions

When flying in gusty weather conditions, the normal operating airspeed $V_{NO} = 107$ kIAS should not be exceeded for safety reasons. The REMOS **GXis** offers very stable flight characteristics even in heavy weather conditions.

Cruise in rain or with dirty aircraft

Raindrops and bugs affect the performance of the aircraft. Be aware that in these conditions the performance figures will not meet the published figures, as they apply for a clean aircraft under standard atmospheric conditions. Expect a performance loss of 10% to 15%. When flying in rain always activate the carburetor heat.

5 Stall

The REMOS **GXis** is fully controllable when flying at a wide range of airspeeds. At airspeeds below the lower speed limit, the aircraft will display very stable stall characteristics. If the airspeed is reduced by the pilot gradually pulling back on the control stick, aerodynamic buffet will occur, indicating that the aircraft is approaching the stall speed. Should the aircraft then be allowed to stall, the aircraft still will remain controllable. The aircraft can be stalled with flaps both extended or retracted.

Stall without power is very gentle. Depending on actual c.g. no stall occurs, although the elevator is pulled fully back. Stall with power may be a little more abrupt. If the aircraft is allowed to fully stall with full power, one wing may drop.

Conducting a stall maneuver does not require special skills. However, if you are not yet familiar with the aircraft, we recommend you do this exercise only when accompanied by an experienced flight instructor.

6 Slip

The slip is a very stable flight condition and is also very easy to perform. This maneuver is used to increase aerodynamic drag to enable a high rate of descent.

Before establishing a slip, you have to ensure that the airspeed is within the required limits. The operating maneuvering speed may not be exceeded. For 1,320lb AUW this airspeed is $V_O = 88$ KIAS and when flying at 880lb it is just $V_O = 59$ KIAS, for any weight in between, the operating maneuvering speed may be interpolated linearly. If performing a slip with flaps extended, a maximum indicated airspeed of $V_{FE} = 78$ KIAS may not be exceeded.

You will achieve the maximum rate of descent when slipping with flaps fully extended and flying at V_{FE} . Steepest decent, however is achieved with reduced airspeed. Do not fly airspeeds lower than recommended for approach (see section 4).

Conducting a slip does not require special skills. However, if you are not yet familiar with the aircraft, we recommend to do this exercise only when accompanied by an experienced flight instructor.

7 Gliding

The aircraft can glide well with the engine off. Best glide ratios are achieved within an indicated airspeed of 60 kIAS. These speeds will establish a glide ratio of about 1:11 with the flaps retracted (0° position).

8 Descent

When descending from level flight it is important to monitor engine temperatures. During descent, the temperatures will decrease. The water cooling system has a thermostat installed, hence the water temperature will not drop too much. However, the oil system does not have a thermostat installed, therefore some power may be needed to maintain safe oil temperatures.

9 Approach

Approach under normal conditions

Always land on the most suitable runway, taking into consideration wind direction, length of runway, obstacles on the approach, etc. It is recommended to fly the approach at 60 kIAS. The recommended target airspeed (airspeed on short final in app. 50ft altitude) for approach at MTOW (1,320 lb) is 60 kIAS and decreases down to 50 kIAS with an aircraft weight of only 1,000 lb.

Approach under tailwind conditions

When on final approach with a tailwind component, the REMOS **GXiS** does not require different approach or flare procedures than those used in calm or headwind conditions. However, you do have to keep in mind that the landing distance will increase significantly.

Approach in crosswind conditions

Crosswinds do not have a big effect on the flight characteristics of the REMOS **GXiS**, as long as the cross-wind component stays within the maximum demonstrated speed of up to 15 kts. Performing a crosswind landing does not require above-average piloting skills. Nevertheless, if not yet familiar with the aircraft, we recommend that you perform crosswind landings only when accompanied by an experienced flight instructor until sufficient experience has been gained.

Approach in turbulent weather conditions

It is recommended to fly the approach at 60 kIAS. The recommended target airspeed (airspeed on short final in app. 50ft altitude) for approach at MTOW (1,320 lb) is 52 kIAS and decreases down to 45 kIAS with an aircraft weight of only 1,000 lb.

9 Approach

Approach in rain showers

Raindrops on the wing surfaces influence the aerodynamic characteristics of the airfoil; drag will increase while lift decreases. The airfoil used on the REMOS **GXis** features stable flight characteristics in rainy conditions. Therefore, there are no special advisories for flights within rain. We recommend that you operate the aircraft as you would in turbulent weather conditions (see "Approach in turbulent weather conditions"). When flying in rain always activate the carburetor heat.

Approach in the slip configuration

If a high descent rate is required on final, we recommend that you conduct a slip maneuver. Conducting an approach in the slip configuration does not require special skills, however, if you are not yet familiar with the aircraft we recommend that you do this exercise only when accompanied by an experienced flight instructor.

Advise

In landing configuration, the airplane is very draggy and the propeller provides additional braking. Therefore, airspeed bleeds off quickly during flare.

It is easy to misjudge altitude during flare. When flare is initiated too high and airspeed bleeds away the airplane may stall or bounce.

In doubt or without an urge to achieve shortest landing distance as possible, or when not yet familiar with the REMOS **GXis**, it is recommended to keep a higher target airspeed. This will give you a reserve airspeed to balance any unexpected deviations in altitude and heading.

Rule of thumb: Keep it at sixty knots, or use all your guts.

In more gusty conditions it may be beneficial to stabilize the glide slope by keeping the flap setting to the 15° position.

10 Touchdown

The aircraft has very good low speed characteristics and so is very controllable all the way through the landing phase. After a good approach has been conducted, the REMOS **GXis** does not require much action to land with a perfect touch down. It is important to establish a safe and stable airspeed during the approach.

Imprint

intentionally left blank

Imprint

Pilot Operating Handbook REMOS **GXiS**
Supplement Flight Training

ASTM Edition

Copyright REMOS AG
© REMOS 2017, all rights reserved

REMOS



REMOS GXiS

POH Supplement – Continued Airworthiness

Continued Airworthiness

Table of Content

| sect. | description | page |
|--------------|---|-------------|
| 1 | Purpose | 10-2 |
| 2 | Continued Airworthiness System | 10-3 |
| 3 | Owner/Operator Responsibilities | 10-5 |
| 4 | Release of Notices to the Public | 10-7 |
| 5 | Documentation Update | 10-8 |
| 6 | Maintenance and Annual Condition Inspection | 10-9 |
| 7 | Modifications or Change of Equipment | 10-10 |
| 8 | Repairs | 10-12 |
| 9 | Contact Data | 10-13 |

1 Purpose

Continued Airworthiness is everything that is required to keep an aircraft in a safe condition to fly. This does not only include the technical part like maintenance and annual condition inspection. It also includes update of documentation, e.g. Pilot Operating Handbook, issuing repair instructions and repair approvals, change on equipment and feedback of the customer to the manufacturer. Especially the latter one is really important as this is the only way that the manufacturer gets to know of potential issues of safety of flight.

In some areas the procedures of the continued airworthiness system of an LSA differ significantly from the ones of a standard category aircraft. This POH supplement shall give guidance to the customer how to act correctly in the continued airworthiness system and how to keep his aircraft airworthy and legal to fly.

2 Continued Airworthiness System

REMOS AG shall be informed about potential issues of safety of flight or service difficulties by means of the Customer Feedback Form G3-8 MA CA 0050. This document is attached to the maintenance manual and is also available on the website www.remos.com. If a customer does not inform the manufacturer by means of this form, REMOS AG also accepts any way of information as long as it contains at least following information:

- aircraft make and model
- serial number and callsign
- propeller make and model
- total time of aircraft and engine
- use of aircraft: private or commercial
- name and contact data of reporting person
- description of potential issue of safety or service difficulty

Once the customer has notified REMOS AG, the information will be forwarded immediately to the Head of Design by means of the customer feedback form.

Shall the customer opt for e-mail notification via service@remos.com then this e-mail will immediately forwarded to the Head of Design.

Based on the information given in the customer feedback form, the Head of Design will perform a risk assessment. In most cases, the Head of Design will contact the customer to collect more and precise information. This includes eventual cooperation with authorities, e.g. in case of an accident.

2 Continued Airworthiness System

A risk assessment consists of:

- cause of accident/incident by pilot error or technical background
- safety effect determination
- risk assessment evaluation
- decision of required alerting of the public
- decision of corrective action

The continued airworthiness system of REMOS AG does not only cover events that have occurred during operation of the aircraft. Proposals for improvements or corrections, service difficulties, findings during maintenance events or annual condition inspections are also covered by the continued airworthiness system. In case that service staff identifies a potential safety of flight issue or a real service/maintenance problem, a customer feedback form must be filled out and handed forward to the Head of Design.

The customer shall not be afraid of consequences like revoking licenses. This is not the intention and not the job of an aircraft manufacturer. If there is no immediate danger for other customers or the flying public, REMOS AG will never notify authorities.

3 Owner/Operator Responsibilities

During handover of the aircraft the owner/operator is introduced into the continued airworthiness system of REMOS AG. The customer is informed about the following:

- The maintenance handbook provides all information that the customer needs to comply with the regulations, especially with continued airworthiness and maintenance.
- It is the owner/operator's responsibility to provide the manufacturer with current contact information. Only with current contact information the manufacturer is able to contact the customer in case service bulletins or safety alerts need to be sent out.
- In case a safety of flight issue or significant service difficulty reveals, it is the responsibility of the owner/operator to inform the manufacturer. The owner/operator shall not seek for solutions on his own and modify the aircraft in a way that is not covered by the maintenance manual.
- Shall the manufacturer release a notice of corrective action it is the responsibility of the owner/operator to comply with it. Furthermore the owner/operator has the responsibility to comply with all applicable aviation authority regulations in regard to maintaining the airworthiness of the LSA airplane.
- In case the manufacturer has released a notice of corrective action the owner complete it within the timeframe defined in the notice. If there is no timeframe defined, then the latest time to comply with it is the next annual condition inspection.
- In case the owner/operator does not comply with the maintenance manual and/or releases of corrective action, the LSA is not in compliance with the accepted ASTM consensus standards. This means that the aircraft is not airworthy and operating this aircraft is not legal. In case the responsible aviation authority (in case of the USA this is FAA) gets to know about this the owner/operator may be subject to regulatory action by the authority.

3 Owner/Operator Responsibilities

This information is provided by means of the customer commitment form, which is part of the maintenance manual. The owner/operator shall sign this form and send it to REMOS AG. On this form the owner/operator shall also provide the manufacturer with current contact data.

If the aircraft is sold to another customer a new customer commitment form needs to be signed. This form will have the identical document number added by a dash and a counting number starting with 1 to make clear that this new form is a new revision.

4 Releases of Notices to the Public

There are three different levels of notices to the public, each representing a different level of importance:

- **SAFETY ALERT**
will be issued in case of an urgent safety of flight situations. Potentially an emergency safety of flight action is required in this case. All safety alerts will be published on the website www.remos.com which is the central means of communication of REMOS AG to its customers.
- **SERVICE BULLETIN**
will be issued in case a corrective action, a mandatory inspection or a modification of the aircraft is required. An immediate action is not required but a future action is required or recommended. All service bulletins will be published on the website www.remos.com which is the central means of communication of REMOS AG to its customers.
- **NOTIFICATION**
will be issued in case service information is required. The public is notified via the website www.remos.com which is the central means of communication of REMOS AG to its customers.

5 Documentation Update

Any documentation update will be released on the website www.remos.com. Owner/operators will not be informed by postal mail, unless such a documentation update is mandatory for safety of flight and is released by a safety alert or a service bulletin. Examples for documentation updates are new revisions of:

- Pilot Operating Handbook
- Service and Maintenance Checklist
- Annual Condition Inspection Checklist
- Type Design Datasheet

For copyright reasons a new revision of the maintenance handbook is not available on the website, but only on request as hardcopy.

6 Maintenance and Annual Cond. Inspection

Maintenance intervals of all REMOS aircraft are 25h for the first maintenance event, followed by 100h inspections. In case that AVGAS 100LL is used for more than 30% of the time, oil change interval is reduced to 50h.

REMOS AG hereby defines the following persons that may perform maintenance and repair as defined in the Maintenance Manual including 25h and 100h inspection:

- Owner/operator: with Sport Pilot Certificate or higher: preventative maintenance, or line maintenance.
- LSA Repairman Maintenance: preventative maintenance, line maintenance, or heavy maintenance.
- A&P Mechanic: preventative, maintenance, line maintenance, or heavy maintenance.
- Part 145 Repair Station with appropriate ratings: preventative maintenance, line maintenance, or heavy maintenance

REMOS AG hereby defines the following persons that may perform the annual condition inspection:

- LSA Repairman Maintenance
- A&P Mechanic
- Part 145 Repair Station with appropriate ratings

Always use REMOS documents for your maintenance events and the annual condition inspection. These documents are available on the website www.remos.com

7 Modifications or Change of Equipment

Certified equipment is listed in the maintenance manual. Only listed equipment may be installed on the aircraft without notifying REMOS AG. In case equipment that is described in the maintenance manual shall be exchanged on the aircraft, it is required to:

- update equipment list
- weight and balance

Modifying the aircraft or changing equipment may be performed by any competent person. Updating the equipment list and the weight and balance report may only be performed by

- LSA Repairman Maintenance
- A&P Mechanic
- Part 145 Repair Station with appropriate ratings

Any change that is not documented may not be performed on the aircraft without having it certified by REMOS AG. Nevertheless, it is possible to do so. Notify REMOS AG prior to the intended change of the aircraft. Engineering department will then decide which kind of documentation is required and will either prepare them or will ask the customer to have this documentation prepared. Followed by this a Letter of Approval (LOA) will be prepared that needs to be signed by either an A&P Mechanic or a Part 145 Repair Station with appropriate ratings after the work is accomplished. Then this LOA will be signed by the Head of Design of REMOS AG and handed out to the customer. This procedure will be performed by e-mail.

The extent of work cannot generally be defined; it is always an individual project. Working hours of the engineering department will be charged by the hour according to actual pricelists.

This procedure is not intended and built up for the manufacturer to make money of it. In contrary, due to running projects within engineering department it usually costs more to prepare the documentation than it is charged for. This procedure is defined in the regulations, in this case ASTM F2483.

7 Modifications or Change of Equipment

Without having updated the equipment list and weight and balance or not having changes approved by the manufacturer that are not part of the maintenance manual, the aircraft is considered not airworthy and unsafe to fly. It is not legal to operate an aircraft without a current equipment list and weight and balance and required approvals by the manufacturer. Make sure the change of equipment is signed off in the aircraft's logbook and is entered in the aircraft's permanent record.

8 Repairs

Repairs are handled similarly as change of equipment. Any repair that is performed with standard tools by replacing damaged parts may be performed by any competent person. To release the aircraft back to service the repair must be signed off by

- Owner/Operator with at least a Sport Pilot Licence
- LSA Repairman Maintenance
- A&P Mechanic
- Part 145 Repair Station with appropriate ratings

It is recommended to perform a standard maintenance event and an annual condition inspection once a repair has been performed that could affect safety of flight.

Structural repairs that are described in the maintenance manual are handled identically. In case the damage exceeds the described ones, an individual repair instruction is required. In this case notify REMOS AG by means of the customer feedback form. Engineering will then prepare individual and precise repair instructions. Repairing a composite aircraft is completely different from repairing a metal aircraft or a composite boat. Therefore only competent persons may perform the work. REMOS AG hereby defines the following persons that may perform the repair:

- LSA Repairman Maintenance with composite knowledge
- A&P Mechanic with composite knowledge
- Part 145 Repair Station with appropriate ratings

Notify REMOS AG prior to the intended repair. Engineering department will then decide which kind of repair and documentation is required and will either prepare them or will ask the customer to have this documentation prepared. Followed by this a Repair Approval (LOA) will be prepared that needs to be signed by either an A&P Mechanic or a Part 145 Repair Station with appropriate ratings after the work is accomplished. Then this Repair Approval will be signed by the Head of Design of REMOS AG and handed out to the customer. This procedure will be performed by e-mail.

8 Repairs

The extent of work cannot generally be defined; it is always an individual project. Working hours of the engineering department will be charged by the hour according to actual pricelists.

This procedure is not intended and built up for the manufacturer to make money of it. In contrary, due to running projects within engineering department it usually costs more to prepare the documentation than it is charged for. This procedure is defined in the regulations, in this case ASTM F2483.

Without having the repair performed and approved according to the manufacturer's instruction the aircraft is considered not airworthy and unsafe to fly. It is not legal to operate an aircraft without current documentation and required approvals by the manufacturer. Make sure the repair is signed off in the aircraft's logbook and is entered in the aircraft's permanent record.

9 Contact Data

The manufacturer of the REMOS aircraft and the only reliable and legal source for continued airworthiness is

REMOS AG

Franzfelde 31
D-17309 Pasewalk

G E R M A N Y

Tel: +49-3973-225519-0

Fax: +49-3973-225519-99

Email: service@remos.com

Web: www.remos.com

Imprint

Pilot Operating Handbook REMOS **GXiS**
Supplement Continued Airworthiness

ASTM Edition

Copyright REMOS AG
© REMOS 2017, all rights reserved

REMOS



REMOS GXiS

POH Supplement – Abbreviated Checklists

Supplement Abbreviated Checklists

intentionally left blank

Supplement Abbreviated Checklists

Purpose

No matter if the airplane is operated according to non-commercial or commercial operating regulations, the pilot is obliged to use cockpit checklists.

The checklists provided in the POH sections 3 (emergency procedures) and 4 (normal procedures) are very comprehensive and therefore sometimes a bit inconvenient to use. Therefore, third parties often offer abbreviated checklists that are often used in the cockpit. These checklists are neither approved nor controlled by the airplane manufacturer and therefore not necessarily complete or correct.

| | |
|-------------|--|
| NOTE | REMOS encourages the pilot NOT to use third party abbreviated checklists, but checklists released by REMOS only. |
|-------------|--|

This POH supplement section 10 offers abbreviated checklists released by REMOS. By using these abbreviated checklist, the pilot in command acknowledges that the content is abbreviated and might be incomplete. Always refer to sections 3 and 4 for full version of these checklists.

| | |
|-------------|--|
| NOTE | Always refer to POH sections 3 and 4 for full version of these checklists. |
|-------------|--|

Supplement Abbreviated Checklists

intentionally left blank

Supplement Abbreviated Checklists

CHECK BEFORE ENGINE START

preflight check OK
 seat belts FASTENED
 brake SET

ENGINE START

ignition key AVIONIC
 avionic SET UP
 ignition key ENGINE
 engine start START
 oil pressure min. 2.0 bar

ENGINE RUN-UP

oil temperature min. 50°C
 engine speed 4.000 rpm
 engine TEST TEST
 rpm drop max. 180 rpm
 main fuel pump OK

TAKE-OFF

departure BRIEFED
 flaps CLEAN
 engine FULL POWER
 lift-off 45 kIAS
 climb 60 kIAS

CLIMB

flaps CLEAN
 engine FULL POWER
 best climb 60 kIAS

CRUISE

power setting AS R'QRD
 engine parameters OK

DESCENT

flaps CLEAN
 power setting AS R'QRD

LANDING

approach BRIEFED
 flaps DOWN
 approach speed 60 KIAS

SHUTDOWN

brake SET
 ignition key OFF

AIRSPPEED LIMITATIONS for MTOW

demonstrated x-wind 15 kts
 stallspeed flaps 35° 40 kIAS
 stallspeed flaps clean 44 kIAS
 best angle of climb 50 kIAS
 best rate of climb 60 kIAS
 max. flap extended 78 kIAS
 max. maneuvering 88 kIAS
 max. turbulence 107 kIAS
 never exceed speed ... 135 kTAS

FUEL

total 84 ltr
 usable 80 ltr
 grade AVGAS, MOGAS, E10

ENGINE PARAMETERS

RPM warmup 2.000 rpm
 max. cont. speed. 5.500 rpm
 max. speed 5.800 rpm
 max. cooling temp. 120°C
 min oil temp. 50°C
 max. oil temp. 130°C
 max. EGT 950°C
 oil pressure 2.0 ... 5.0 bar
 fuel pressure 2.8 ... 3.2 bar

**THIS IS AN ABBREVIATED CHECKLIST. REFER TO PILOT
 OPERATING HANDBOOK SECTION 4 FOR FULL VERSION.**

Supplement Abbreviated Checklists

ABBREVIATED EMERGENCY CHECKLIST

AVIATE – NAVIGATE - COMMUNICATE

DECLARE EMERGENCY

SPIN RECOVERY

engine IDLE
 aileron NEUTRAL
 rudder OPPOSITE SPIN
 elevator PUSH

EMERGENCY DESCENT

engine IDLE
 flaps CLEAN
 max. turbulence 107 KIAS
 never exceed speed ... 135 KTAS

ENGINE STOPPAGE ON TAKE-OFF

brakes AS R'QRD
 ignition key OFF

ENGINE STOPPAGE ON CLIMB-OUT

ignition key OFF
 landing STRAIGHT AHEAD

ENGINE STOPPAGE IN FLIGHT

emergency switch START
 SkyView STAY ON
 landing SUITABLE AIRFIELD

GENERATOR FAILURE

emergency switch ON
 SkyView STAY ON
 landing light OFF
 system TROUBLESHOOT

ENGINE FIRE ON GROUND

ignition key OFF
 brakes AS R'QRD
 vacate aircraft IMMEDIATELY

ENGINE FIRE IN FLIGHT

ignition key OFF
 sideslip AS R'QRD
 landing EMERGENCY LANDING

EMERGENCY LANDING

landing site IDENTIFY
 direction of wind IDENTIFY
 flaps DOWN
 ignition key OFF
 approach speed 60 KIAS
 vacate aircraft IMMEDIATELY

**THIS IS AN ABBREVIATED CHECKLIST. REFER TO PILOT
 OPERATING HANDBOOK SECTION 3 FOR FULL VERSION.**

Imprint

intentionally left blank

Imprint

Pilot Operating Handbook REMOS **GXiS**
Abbreviated Checklists

ASTM Edition

Copyright REMOS AG
© REMOS 2007-2017, all rights reserved